


MMTGB

MMTGB Bracket

Installation Instructions


BOX CONTENTS



INSTALLING THE MMTGB BRACKET TO THE GATE CONTROLLER AND GATE

Follow the steps below to attach the MMTGB bracket to cylindrical gate:

- Using the supplied 1" bolt and nut, connect the existing gate arm bracket to the MMTGB brackets. Do not tighten completely.
- With the gate arm in its fully retracted position and the gate set in the desired open position, place the MMTGB onto the desired section of gate. 2 See installation manual for push-to-open instructions.
- Insert the supplied 21/2" bolts through the eyes of the MMTGB, then add washers, and finally attach the nuts. Do not tighten completely.
- Once the MMTGB is in place and arm is mounted snugly to the gate, verify the gate clearances then test the gate opener. Adjust as necessary.
- After verifying the install meets the automatic gate opener specifications, adjust as necessary before tightening all hardware.





Mighty Mule Sales: 800-543-4283 | Mighty Mule Technical Service 800-543-1236

For more information on Mighty Mule's full line of Automatic Gate Operators, Gate Openers and Access Controls visit www.mightymule.com