















Disassembly and cleaning instructions




*Lubricate needle with lube (supplied)



Spare cup
and lid x2

Accessories kit



No. Description

1. Air cap ring
2. Air cap
3. Air direction plate
4. 0.5mm solution nozzle
5. Solution nozzle gasket
6. Pivot screw
7. Washer
8. Main body assembly
9. Solution needle
10. Adaptor
11. Needle spring
12. Solution flow screw
13. Pivot
14. Flexible tube air feed (2 pcs)
15. Inline check valve
16. Gland nut
17. Gland seal (3 pcs)

Part No.

- L0151
L0517
L0162
L0157
L0159
L0179
L0195
L0180
L0166
L0174
L0175
L0176
L0178
L0182
L1402
L0173
L0168

No. Description

18. Trigger
19. Pressure hose stem
20. Lid assembly
21. Gasket
22. Pressure connector
23. Pick up tube assembly
24. Tanning solution cup

Part No.

- L0177
L1401
L0187
L0188
L0183
L0190

Accessories kit

No. Description

15. Inline check valve
17. Gland seal (3 pcs)
21. Gasket
23. Pick up tube assembly
25. Brush
26. Spanner/ wrench
27. Gun lube

Part No.

- L1402
L0168
L0188
L0183
L1403
L0191
SG244