

Lamp Shade Assembly





These ceramic lamps are individually handmade. While I aim for consistency, clay is a wild and wonderful medium that can shift during firing. Some organic nature is to be expected, however, the lamp shade should not appear uneven while attached to the base. To ensure a level fitting, follow these instructions for assembly:

+ Step 1

Place the rubber washer over the threaded rod. Next, place the lampshade on top of the rubber washer. Secure the shade by screwing the finial onto the threaded rod by hand. Make sure the finial is fitted very tightly.

+ Step 2

Step back to see if your shade is resting level on the base. If not, look underneath the shade and find the metal plate that it rests on. This plate tilts back and forth along the top of the harp. If your lampshade looks uneven, gently grab the shade with both hands and tilt it until you've reached a level placement.

+ Step 3

For further adjustments, try removing the finial and lampshade and adjust the placement of the rubber stopper. Reattach the finial and lampshade until it has found a more level resting place.