

Regular Maintenance

Regular maintenance is vital in order to keep the wood floors in a strong and beautiful condition for a long time. Well-kept surfaces also result in fast and easy cleaning and maintenance.



Instructions

- 1. Daily cleaning should be done with vacuum cleaner or broom. The frequency of floor cleaning depends on the wear of the floor.
- 2. Natural Soap must be shaken carefully before use.
- 3. Mix 125 ml(0.5 cup) Natural Soap into 5 l(1.3 Gallons) of lukewarm water. It is recommended always to work with 2 buckets: one with soap water and one with rinsing water. Clean the floor with minimum quantity of water - leave soap water on floor briefly in order to dissolve dirt. Remove dirty soap water with hard-wrung mop or cloth and rinse out in bucket with rinsing water.
- 4. Always wipe floor with soap water on hard-wrung mop or cloth in order to re-establish the protective Natural Soap film

For cleaning and maintenance on smaller areas you can also use premixed, ready-to-use WOCA Intensive Cleaner Spray, WOCA Natural Soap Spray, and WOCA Spot Remover.