

## Professional Bike Pump with Flexi Hose & Pressure Gauge

Screw-in metal head to securely attach to create an air tight connection

Easy 180° valve change for Presta or Schrader

Frame mount and holding strap included

CNC machined Aluminium for longer lasting performance

Comfort handle for smooth inflation

Twist and lock closure system

Pressure gauge and flexible hose

Note: You will need to inflate to 20psi before the pressure gauge starts reading your tyre pressure.

## Additional Adapters Included With Every Pump



Sports ball needle and inflatables adapters also included. All 3 adapters slot into the pump head to easily inflate.






Your pump is supplied ready to inflate using a Schrader valve. It is easy to switch to set up for Presta valves too. Simply follow the instructions below:

Presta (French / Road)



Schrader (American / MTB)



- 1 Open the pump lid.
- 2 Extend the hose from the top of the pump.
- Unscrew the metal pump head from the top of the hose connector.
- 4 Turn the pump head 180° degrees.
- Place back on to the pump connector and tighten.
- **6** Twist the pump head on to the presta or scrader inner tube valve.
- nflate your tyre using the pump.

Note: You will need to inflate to 20psi before the pressure gauge starts reading your tyre pressure.

To find out more about this product and view helpful how to videos, visit: www.velochampion.cc/pages/instructions