


J SCHATZ

Egg Bird House
User Guide



INTRODUCTION

Your new Egg Bird House is easy to use. Please use this User Guide to:

Assemble and hang the Egg Bird House

Disassemble and clean out the Egg Bird House

Care for the Egg Bird House

EGG BIRD HOUSE PARTS

Your Egg Bird House consists of 5 individual Parts.


1 Stoneware Egg with Vinyl Coated Hanging Wire sealed at the Egg Bird House entry with a Rubber Grommet and Washer

1 Aluminum Perch sealed with a Clear Nylon Hole Protector

1 Aluminum Bottom with Four Ventilation/Drainage Holes

1 Aluminum Pole


1 Hitch Pin



EGG BIRD HOUSE ASSEMBLY INSTRUCTIONS

STEP 1

Turn the egg upside down.




EGG BIRD HOUSE ASSEMBLY INSTRUCTIONS


STEP 2

Position the aluminum bottom upside down in the center of the egg and insert the aluminum pole through one of the ventilation/drainage holes in the aluminum bottom. Slide the pole through the hole until parallel with the aluminum bottom and then slide it back into the opposite hole and center the pole between the holes in the aluminum bottom.


INSERT



ALIGN PARALLEL



CENTER




EGG BIRD HOUSE ASSEMBLY INSTRUCTIONS

STEP 3

Center the hole in the aluminum pole with the hole in the top of the aluminum bottom and insert the hitch pin through the pole hole and into the hole in the top of the aluminum bottom to secure the aluminum bottom in place.


Turn the Egg Bird House over and hang.



EGG BIRD HOUSE DISASSEMBLY INSTRUCTIONS

STEP 1


Turn the egg upside down and remove the hitch pin.



EGG BIRD HOUSE DISASSEMBLY INSTRUCTIONS

STEP 2


Remove the aluminum pole from the aluminum bottom. Slide the pole to the left or right until it clears the opposite hole and then slide outward at an angle.



EGG BIRD HOUSE DISASSEMBLY INSTRUCTIONS


STEP 3

Remove the base to clean out the Egg Bird House and follow the Assembly Instructions to hang.



EGG BIRD HOUSE HANGING GUIDE

Hang the Egg Bird House 3' from surrounding surfaces to prevent animals from disturbing the house. Most animals will not be able to jump onto the slippery surface of the Egg Bird House if hung at least 3' from surrounding surfaces. The Egg Bird House hanging wire is 24" and will need to be connected to an additional length of wire to hang 3' from surrounding surfaces. We recommend using a snap hook to attach the Egg Bird House to the additional length of wire. A snap hook allows the Egg Bird House to easily be removed for cleaning. Snap hooks can be found in most hardware stores.



CARE FOR THE EGG BIRD HOUSE

Wipe clean stoneware and aluminum surfaces with a damp cloth. We recommend cleaning your bird house after each brood has left. Use a 10% bleach to water solution, scrub with a firm brush and rinse thoroughly. Allow to dry. If you live in an area that freezes please make sure the interior of the Egg Bird House remains dry during the critical times of year when it freezes and thaws. Damage to the egg may occur during the freeze/thaw cycles if the interior is wet.



Wonder-Certified™

We certify that the products we make are inspired by wonder. Each day we arrive at the studio motivated to work hard and create exceptional pieces of ceramic ware. We live to capture beauty, be surprised, and solve creative problems with innovative designs. Most importantly, we love what we do. 28,000 wonder-certified ceramic products have been sold since 2004 to satisfied customers throughout all fifty states and around the world in 14 countries. Handmade with wonder in our Boothbay Harbor studio one piece at a time.

CUSTOMER SERVICE CALL 866-344-5267

Weekdays 9a.m. - 5p.m. EST

OR VISIT WWW.JSCHATZ.COM

Follow J Schatz on Facebook, Twitter, or Instagram:

facebook.com/jschatzstudio

twitter.com/jschatzstudio

instagram.com/jschatzstudio

Wonder-Certified, and J Schatz are trademarks of J Schatz, Inc.

©2021 J Schatz. All Rights Reserved.