



AUTHORIZED DEALERS



Step 1:

Download & Install the AutoAgent App

The AutoAgent app is available for most mobile devices. It may require that your mobile device has been updated to the most recent operating system.

Step 2:

Create an account

From the AutoAgent app, select *'create an account'*. You will need to verify that your email address is valid upon creation.

Step 3:

Place Your Key in the 'Run' Position

Turn your key all the way over to the run position without starting the vehicle. This will boot your vehicle's engine computer allowing the AutoAgent to communicate with it. If you have a push-to-start vehicle, you should press the 'Start' button till it is in the run position.

DO NOT START THE VEHICLE

Step 4:

Plug the AutoAgent into your OBD-II Port

With the key in the *'Run'* position, plug your AutoAgent into your vehicle's On Board Diagnostics II port. You can verify that it has booted correctly when you see that a blue and green light is illuminating from the device.

Step 5:

Connect to your AutoAgent via WiFi or Bluetooth

Navigate to the WiFi settings of your mobile device and select the *'EZLYNK_####'* network. A check mark will appear next to the network name when you have successfully connected. The AutoAgent 2 also allows you to connect via Bluetooth.

Step 6:

Open the App & Lynk your Vehicle

After you've successfully connected, you can navigate back to the AutoAgent app. You should now be able to see your vehicle gauges.

It's time to lynk your device with your technician. Under the '*Technicians*' menu, on the top right corner of the app select '+' then enter the email of the technician you have selected for tunes. Proceed to the second step of the lynking process by entering all vehicle modifications done to the truck in order for the correct tunes to properly be built.

AMDP Custom Tuning technician Email: mitch@amdieselperformance.ca

Step 7:

Tune your Vehicle

After your vehicle has been lynked, you're ready to install your custom tunes.

Navigate to '*Vehicle*' > '*ECU Profiles*'. Here you can view the list of tunes that are available to you for your application. Tap the '*cloud*' button to download your desired tune, then select '*Install*' and follow the prompts to complete the programming steps.

EZ Lynk Engine Tuning Abbreviations:

- SOTF - Switch on the fly (If the Vehicle is equipped with a switch)
- FT - Fuel Temp SOTF Switch
- CAC - Charge Air Control SOTF Switch
- LBF - Low Boost Fuel
- RUMBLE - Rumble Idle Sound (VGT Turbos Only)
- HISS - Hiss Idle Sound (VGT Turbos Only)
- Em.on - Emissions On Tuning / Em.off - Emission Off Tuning
- MODVGT - Modified VGT Turbo
- NONVGT - Non VGT Turbo / Fixed Vein Turbo
- 4IN - 4 Inch Intake (Stock)
- 5IN - 5 Inch Instake
- CP3 - CP3 Pump Conversions

EZ Lynk Ford Transmission Tuning / Transmission Tuning Abbreviations:

- **KAM Reset - Load this tune first prior to installing any modified trans tuning files (FORD)**
- LSP - Low Shift Points
- SSP - Standard Shift Points
- RSP - Raised Shift Points
- HSP - High Shift Points
-

EZ Lynk Alternative Abbreviations:

- ST – Single Fuel Tank
- DT – Dual Fuel Tank
- SRW – Single Rear Wheel
- DRW – Dual Rear Wheel
- MAN – Manual Transfer Case
- ELEC – Electric Transfer Case