

# Eggshell Smart Diffuser **USER MANUAL**

# TABLE OF CONTENTS

SMART LIFE SET UP	3
APP CONTROLS	4
PAIRING YOUR DEVICE	5
USING YOUR DIFFUSER	6
COMPONENTS	7
BUTTONS & MODES	8
MAINTENANCE	9
TROUBLESHOOTING	10
SAFETY AND CARE	11

# SMART LIFE SET UP

Download Smart Life for mobile.



## Registration

You can register for an account using your email address or phone number.

## Obtain Verification Code

A code will be sent to your email address or phone for verification. Please check your junk mail or spam folder if you do not receive it.

## Adding the Diffuser

1. Click the ⊕ icon on top right to add device.
2. Use “Auto Scan” and follow the instructions on screen
3. Alternatively click “Add Manually”, select “Small Home Appliance” on left sidebar. Select diffuser icon.
4. Select 2.4 GHz Wi-Fi Network and enter password, then click “Next” and follow instructions in the app.

# APP CONTROLS

Main	
OFF TIMER	Selects duration of operation
DIFFUSER ICON	Select mist strength
ENABLE/DISABLE MIST	Toggles mist On/Off

DIFFUSER LIGHT	
SET COLOR	Select color from palette
RANDOM COLOR	Colors change randomly

ADD SCHEDULE	
SCHEDULE	Set operation timing
LAMP NAME	Edit name of the light

# PAIRING YOUR DEVICE

## Alexa

1. Select “Skills” in the sidebar and search for “Smart Life” in the search field.
2. Press the “Enable Skill” button.

## Google Home

1. Select “Add”.
2. Select “Set up device”.
3. Go to “Manage Accounts”, scroll down and select “Smart Life”.
4. Select “Link Now”.

## Unpairing your device


The Diffuser Lamp must be unlinked from the current account before it can be linked to another.

In the main APP UI, click the icon on the top right corner, then select “Remove Device” in the details page to unbind your device.

# USING YOUR DIFFUSER

1. Lift the lid to open
2. Connect the power source
3. Fill with water up to no more than 1600 ml  
(below the max line indicated)
4. Add 3-5 drops of essential oil
5. Align the lid with the groove to close
6. Press the mist and light button to turn on,  
control with paired Smart Life mobile app

# COMPONENTS



# SPECIFICATIONS

Product Size	24.1(W) x 17.4(D) x 14.9(H) CM
Power	24W
Net Weight	0.945 KG
Water Capacity	1600 ML
Operating Temperature	0 °C - 40 °C

# BUTTONS & MODES

## LIGHT BUTTON


Action	Status
1st Press	Light auto-change
2nd Press	Fixes on a color during auto-change
3rd - 14th Press	Goes through colors
15th Press	Turns off light

## MIST BUTTON


Action	Status
1st Press	Low mist mode
2nd Press	Middle mist mode
3rd Press	High mist mode
4th Press	Turns off mist



# MAINTENANCE



Carefully wipe the surface of the mist chip with a cotton swab to remove dirt. Do not touch it with any sharp objects.



Drain excess water in this direction.



Do not get any water into the air outlet.

# TROUBLESHOOTING

## Light is on but there is no mist

- Reconnect to the power source
- Check if diffuser is over-filled
- Check if diffuser lid is closed properly
- Water may have entered the circuit board, power off the diffuser and let it dry

## No indicator light

- Reconnect to the power source

## Leakage

- Check that diffuser lid is closed properly

## Weak Mist

- Check if diffuser is over-filled
- Check if lid is closed properly

# SAFETY AND CARE

- Use in a well ventilated place.
- Clean the tank regularly.
- Do not use water with a temperature in excess of 60°C.
- Do not pour water into the air outlet, this will result in malfunction. If any water gets in, cease operation and allow the diffuser to air dry.
- Keep the product out of reach of young children.
- Avoid exposing product to the following:  
Strong magnetic fields, dusty environments, reactive liquids.
- Use water-soluble essential oil.