


CONTROLS



Long press to turn on/off Short press to select spray modes

Spray Modes

15 sec Spray for 15 seconds and stop for 165 seconds 60 sec Spray for 60 seconds and stop for 120 seconds 120 sec Spray for 120 seconds and stop for 60 seconds



Short press to select timer.

When there is no timer indicator light displayed, the diffuser is on continuous working mode.

Please charge your diffuser with a charger with DC 5V output. The power indicator will flash during charging. Once the battery is full, the power indicator stops flashing and turns to red.

USAGE NOTES

Thank you for purchasing the YUN Nebulizing Diffuser.

This diffuser is designed to be used indoors, please read this manual carefully.

MAX DIFFUSING COVERAGE

60 - 100 m²

OPERATION TIME

On full charge, the diffuser can last up to 72 hours depending on the spray mode.


SAFETY PRECAUTIONS

- Do not point the spray nozzle at any person, animal or pet during operation.
- 2 Do not disassemble or modify this diffuser.
- 3 After the diffuser oil bottle is fitted in the diffuser, do not tilt or turn over the diffuser to prevent the oil from leaking into the diffuser, which may result in damage. To install or change a diffuser oil bottle, please turn off the diffuser first.
- 4 The recommended operating temperature is 10°C 40°C.
- 5 Do not wash the diffuser under running water or submerge under water.

INSTALLING THE DIFFUSER OIL BOTTLE



- 1. Push the spray nozzle out from the bottom of the diffuser.
- 2. Screw the diffuser oil bottle into the spray nozzle.
- 3. Replace the spray nozzle that is now attached to the diffuser oil bottle from the top and align the triangles, ensuring that the nozzle is level with the top of the diffuser.



NOTES

The spray nozzle can be fitted with 5 ml, 10 ml or 15 ml diffuser oil bottles.

The diffuser will not create mist with water.

TECHNICAL SPECIFICATIONS

Diffuser Oil Bottle Capacity 5 - 15 ml

Voltage DC 5 V

Power 1.5 W

Battery Max Running Time 72 H

Battery Capacity 2000 mAh

NOTES

Please use a charger that is rated with DC 5 V output and is safety tested.

The power indicator will flash during charging. Once the indicator stops flashing and turns to red, this means the battery is fully charged.

After repeated charging and usage, the efficiency of the battery will gradually become lower and lower.

FAQ

Why can't I turn on the diffuser?

Please ensure that the diffuser is sufficiently charged.

Why is there no mist?

Please check if the diffuser oil bottle has oils. The diffuser wil only work oils and cannot work well with oils diluted by water.

You can also check if the nozzle or straw is blocked. These can be cleaned using alcohol.

If the nozzle is still blocked especially after some time of no usage, you can clear the nozzle by pouring alcohol into diffuser oil bottle and operating the diffuser for 3 hours.