

GARMENT CARE SYMBOLS

WASHING

LC		LG	LH	LI	LJ	LK	LL		LD	LE	LF
Hand-wash only. Rinse normally and dry with care.		Machine wash at the indicated maximum temperature in degrees Celsius							Do not wash	One bar indicates that the spin speed should be reduced Two bars means the clothes need a mild wash action, but can be spun and rinsed normally	
LM	LS	LN	LT	LO	LU	LP	LV	LQ	LW	LR	LX
The lines underneath the symbol indicate the type of programme to use: One line Synthetic programme Two lines Wool programme											

DRYING

UT	UV	UW	UX	UU	N6	N8	N7	N9
Can be tumble-dried. Dots in the middle indicate the maximum temperature: No dot No temperature restriction One dot Low-temperature dry (maximum 60°) Two dots Normal dry Three dots High temperature dry				Do not tumble-dry	Hang up to dry.	Leave to air-dry and iron as soon as dry	Dry flat	Dry in the shade

IRONING

UD	UE	UF	UC
Iron at the following temperature: One dot Warm iron (110°) for acrylic, nylon and acetate Two dots Hot iron (150°) for polyester and wool Three dots Very hot iron (200°) for cotton and linen			Do not iron

DRY CLEANING AND BLEACHING

UL	UK	UJ	UM	UL	UN	UG	UI	UH
Dry clean only. indicates the type of clean required. P is the most common, indicating that the usual solvents are needed.	Do not dry clean	This garment is suitable for dry cleaning	Dry clean: hydrocarbon solvent (HCS) only	Dry clean: PCE only	Professional wet cleaning	You can safely use a cold, dilute solution of bleach	triangle with stripes - only a non-chlorine, colour-safe bleach should be used	Do Not Bleach

Please forward the code from under each required symbol

Examples:-

LG	UU	UD	UK	UH

LH	UV	UC	UJ	UH

LC	UU	UC	UK	UH