

SAFETY INFORMATION

- WARNING: strangulation hazard – long cord.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon zinc), or rechargeable batteries.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Exhausted batteries are to be removed from the toy to prevent leakage.
- Remove batteries if product will not be used for a long period of time.

Conforms to the requirements of ASTM standard consumer safety specifications on toy safety F963.

Not recommended for children under three years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.

WARRANTY INFORMATION

Little Experimenter provides a limited warranty to the original purchaser that this product is free from defects in materials and workmanship under normal use for a period of thirty (30) days from the original date of purchase. Little Experimenter's responsibility, with respect to this limited warranty; shall be limited solely for the purpose of repairing or replacing, (at our discretion), products which fail during normal consumer use. To obtain warranty coverage during the Warranty period, contact your place of purchase ("Seller") to obtain a return authorization, and return the defective product to the seller along with proof of purchase. This warranty does not extend to damage or failure which results from misuse, neglect, accidents, alterations, abuse, improper installation or improper maintenance. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.


**Little
Pretender®**



Karaoke Stage Microphone

OWNER'S MANUAL

Item #4766



Manufactured
and Imported by:

**Little
Pretender®**

BROOKLYN, NY 11205
www.littlepretender.com
© 2019 LITTLE PRETENDER


**Please keep these instructions
for future reference.**

WARNING:
CHOKING HAZARD - Small parts.
Not suitable for children under 3 years.



CONTENTS:

1. Music Base
2. Adjustable Stand Pole
3. Mic Holder
4. Desk Adapter
5. 2 Microphones
6. Aux Cable
7. 4 x "AA" Batteries




The Music Base of Little Pretender Stage Karaoke can be used either as an Adjustable Mic Stand or as a Desk Stand.


ASSEMBLY:

ADJUSTABLE STAND:

1. Insert the Adjustable Stand Pole into the designated hole on the Music Base.




2. Adjust the Stand Pole to a comfortable height by pulling up the two inner poles as much as necessary.




DESKTOP STAND:


1. Insert the Desk Adapter into the designated hole on the Music Base.



2. Remove the Mic Holder from the Adjustable Stand Pole.



3. Attach the Mic Holder to the Desk Adapter.



MUSIC BASE FEATURES:

- | | | |
|-------------------------|---------------|---------------------|
| 1. Music Button | 4. Aux Input | 7. Speaker |
| 2. Power/Volume Control | 5. Mic 1 Port | 8. Flip Out Handle |
| 3. Applause Button | 6. Mic 2 Port | 9. Stand Receptacle |

