

K2006A Master Barber Chair





Dimensions:

Seat Cushion 22" wide by 19" deep by 6" thick


Back Cushion 22" wide by 18.5" high


Armrests
Outside to Outside = 30"
Inside to Inside = 19"

Floor to Seat Height Lowest Position = 24" Highest Position = 31"

Chrome Kickplate

Reclining Levers on Both Sides of Chair





See more details on these bases at $\underline{www.kellerinternational.com}$ – on the parts page.









The headrest has an "infinite" number of positions because of the wedging rollers at the bottom of the rectangular shaft under the Headrest Pillow.

Just pull UP on the headrest to whatever height is desired and let go – the headrest will stay in that position until a lever is lifted to lower the headrest.

The headrest can also be completely removed from the Barber Chair.

The maximum recline (see the picture below) is around 50° to facilitate shaving.

The footrest rises as the Barber Chair is reclined.

