



**KELLER INTERNATIONAL, LLC**  
1431 LAKE RD, HAMLIN NY 14464  
Info@kellerinternational.com  
T: 1-800-578-8772 ▪ F: 1-585-964-8093  
**KELLER4SALON.COM**

## K2096 Vintage Barber Chair



- Chair comes completely assembled
- Drop Footrest Plate and re-install bolts.
- Chair weighs about 200 pounds.
- Factory Safe Weight Specification:  $\geq 450$  pounds.
- All metal surfaces have been antiqued.



**Headrest Dimensions**  
8.0" by 5.0" by 4.5" dia.

**Back Cushion Dimensions**  
20.5" wide by 17.0" high

**Seat Cushion Dimensions**  
20.5" wide by 19.0" deep & 3" thick

**Floor to Seat Height Dimensions**  
Lowest = 21.0"  
Highest = 28.5"

**Armrest Dimensions**  
Inside to Inside = 20.5"  
Outside to Outside = 26.5"

**Legrest Pillow Dimensions**  
11.5" wide by 4.5" high

**Ankle Pillow Dimensions**  
14.0" wide by 6.0" high

**Footrest Plate Dimensions**  
15.0" wide by 11.0" deep

**Circle Base = 26.0" diameter**

**Chair Back Reclines**  
100° to 150°








- **The top picture shows the shroud covering the hydraulic pump with the antiqued base plate (the shroud is a light creamy white color – not as shown).**
- **The bottom picture shows the foot plate feet plus the ankle pillow.**



- **Bringing back the classic barbershop values and engineered with a modern design, the Keller Vintage Barber Chair is the newest addition to our collection.**
- **Recline Lever Handle is on the right side of the chair (when standing behind the chair).**
- **This Barber Chair features heavy-duty white fiber glass from top to bottom.**
- **This Barber Chair also features towel hangers under each armrest, a flip up footrest, and authentic metal accent calf rest with plush cushioning for additional client comfort.**
- **Upholstered with rustic leather like vinyl.**



- **Adjustable headrest heights.**
- **Six (6) detent positions.**
- **Maximum headrest height is 6-inches.**
- **Pull the headrest UP to the desired height (no need to press the detent button).**
- **To lower the headrest – press the detent button and hold – until the headrest is in the desired position – make sure the detent button locks into a circle cutout on the headrest shaft.**
- **The headrest can also be completely removed.**
- **Headrest is approximately 4.5-inches in diameter.**

