



Supplied hose

Instructions to connect the hose to the submersible pump for your fountain:

- Make sure that your fountain is in place and ready.
- Take the provided hose and feed it down through the center drilled hole in the stone fountain. The hole is approximately 1.25" in diameter, which will leave space around the hose. There is a plug on one end which will friction fit at the top of the fountain drilling. Depending on the size of your pump, you will have been supplied either a 1/2" or 5/8" diameter hose.
- We wrap one end of the hose with a strip of pond liner and electrical tape to ensure a tight fit at the top of the drilled hole. If the plug is too small to stay in place, you may need to remove the electrical tape and add some pond liner then retape to increase the diameter.
- Finally, connect the end of the hose in the reservoir to the submersible pump sitting on the floor of the reservoir.



steps to creating the plug end of the hose