

Franklin Electric Co., Inc.
 P. O. Box 12010
 Oklahoma City, OK 73157-2010
 405.947.2511 • Fax: 405.947.8720
 www.LittleGiantPump.com
 CustomerService-WTS@fele.com

EN INTRODUCTION

This instruction sheet provides you with the information required to safely own and operate your Little Giant product. Retain these instructions for future reference.

The Little Giant product you have purchased is of the highest quality workmanship and material, and has been engineered to give you long and reliable service. Little Giant products are carefully tested, inspected, and packaged to ensure safe delivery and operation. Please examine your items carefully to ensure that no damage occurred during shipment. If damage has occurred, please contact the place of purchase. They will assist you in replacement or repair, if required.

READ THESE INSTRUCTIONS CAREFULLY BEFORE ATTEMPTING TO INSTALL, OPERATE, OR SERVICE YOUR LITTLE GIANT PRODUCT. KNOW THE PRODUCT'S APPLICATION, LIMITATIONS, AND POTENTIAL HAZARDS. PROTECT YOURSELF AND OTHERS BY OBSERVING ALL SAFETY INFORMATION. FAILURE TO COMPLY WITH THESE INSTRUCTIONS COULD RESULT IN PERSONAL INJURY AND/OR PROPERTY DAMAGE!

INSTALLATION (DFB36)

Refer to Figure 1 and the following instructions to install the DFB36 basin:

1. Dig a hole 9" deep, 30" in diameter at the bottom, and sloping to 35" in diameter at the top. Ensure that the ground at the bottom is level and solid.
2. Place the basin into the hole, with the power cord cut-out facing toward the power source.
3. Set the support into the circular receptacle in the center of the basin and align the tubing cut-outs.
4. Place the pump into the basin, running the power cord through the cord cut-out.
5. Cut a length of tubing long enough to reach from the bottom of the basin to the top of the water feature.
6. Run the tubing through the center hole in the top of the support and out the tubing cut-outs, then connect it to the pump outlet fitting.
7. Install the six top plates.
8. Refer to the water feature owner's manual to complete the installation.



INSTALLATION




Figure • Figure • Figura 1 - DFB36