
Manual ZERO-TX




Quick start



- 1. Start charging the earphones in charging box until red LED on earphones turn off.
- 2. Activate Bluetooth® on the transmitting device.
- 3. Take out both earphones from the charging box. They automatically start searching for a device to pair with.
- 4. Select "ZERO-TX" in Bluetooth list of the transmitting device.

Resetting & Wearing



- 1. Reset the earphones by pressing the buttons for 10 sec. The LED:s will start flashing in white and red.
- 2. Put both earphones into the charging box.



Insert the earphone carefully with the mic pointing forward, towards the face.

Charging

Earphones



Insert the earphones into the charging box. The LED:S will shine red during the charing process and turns off when the earphones are fully charged.

Box



There are 4 LED:s indicating the charging box battery status 25%, 50%, 75% and 100% in sequence.

Functions

O Power On

Method 1: Take out the earphone from box. Method 2: Press button 2 sec.



OPPOWER Off

Method 1: Put the earphone into the box. Method 2: Press button 5 sec.



Answer & Hang up Press button 1 time.



@ Decline call Press the button 1 sec.



Switch Audio output

During the call, press the button 1 sec. to switch output between phone & earpone.



Mute On & Off During the call, press the button 2 times.



Play & Pause Press the button 1 time.



C Skip to previous track Press the button 3 times.



Skip to next track Press the button 2 times.



Voice Assistant Press the button 2 sec. to activate eg: Siri or Google Assistant.



Re-dial last calling number



Tips & warning

- 1. Before use, please read the manual carefully.
- 2. The charging box should be fully charged before first use.
- 3. If the earphones are not being used for a month, please charge before use.
- 4. If you have any questions concerning our products, you can reach our customer support at:

support@soundbysweden.se

- 1. Do not store in extreme temperatures, below 0 degrees and +45 degrees Celsius.
- 2. Keep dry during charging and usage.
- 3. Do not use harsh chemicals or strong detergents to clean the earphones and charging box.







