



No matter what your experience level in mountain sports, we invite all from beginner to seasoned vet to LEVEL UP and join in the fun. We don't believe mountain sports should be intimidating. We enable and instill confidence in our customers by providing quality, innovative, easy-to-use gear with impeccable style and creativity. We educate through well-thought-out tips and tricks to help our customers progress their skills on every level. We work to build an inviting, engaging community of mountain sport enthusiasts that encourage others to share in the experience. It's going to be a 'Wild' ride and we hope you'll join us on our mountain adventure!

wildhornoutfitters.com

RADKE PERFORMANCE EYEWEAR

KEY FEATURES:



ADDITIONAL FEATURES:

- Durable snap hinges
- Prescription insert frame included (prescription lenses are not included). Consult your ophthalmologist to have your prescription lenses made and fitted to the included frame.
- Comfort wrap frame stems for a secure fit and bike helmet compatibility

PRINCIPALES CARACTÉRISTIQUES
Lentille en polycarbonate à perspective panoramique pour un maximum de visibilité et durabilité | Protection uv400 100% Fénom™ lens tech (lentilles interchangeables) | Cadre résistant tr90 à design convertible intégral / ouvert | Pont réglable pour un ajustement personnalisé | Plaquettes et manchons confortables et texturés | Construction confortable et légère | Revêtement de la lentille résistant aux rayures | Résistant à la buée | Charnières résistantes | Insertion de cadre à ordonnance comprise (lentilles à ordonnance non comprises) | Tiges du cadre revêtues pour un ajustement sûr et la compatibilité avec le casque de cyclisme

CADRE À DOUBLE MODE / ÉCHANGE DES LENTILLES
Nous avons conçu les lunettes Radke avec un cadre à design unique interchangeable qui vous permet de passer rapidement du cadre intégral au cadre ouvert d'un seul coup :

• Pour enlever le cadre de base, en tenant fermement la partie supérieure du cadre, tirez le coin le plus épais de la partie inférieure du cadre vers le bas (1). Une fois les deux parties séparées, répétez dans le coin opposé. Avec les coins des deux points d'attache libres, tirez la plaque directement vers le bas pour enlever complètement.

• Pour échanger les lentilles (avec le cadre de base enlevé), il suffit de tenir fermement la partie supérieure du cadre et de tirer en même temps la lentille en commençant dans un coin et en l'allant vers l'autre jusqu'à ce que la lentille soit complètement enlevée. Remplacez-les avec vos lentilles préférées en inversant les étapes ci-dessus, en travaillant d'un bout à l'autre du cadre des lentilles jusqu'à ce qu'elles soient bien fixées. Vous allez sentir la lentille s'engager sur place à chaque point de connexion. Après l'installation de la lentille de remplacement, tirez doucement la base de la lentille pour vérifier si elle a été bien fixée. Une fois la lentille fixée, attachez le cadre de base / les plaquettes préférées et vous êtes prêt à pédaler ! Rendez-vous sur wildhornoutfitters.com pour plus d'informations et la sélection complète des lentilles disponibles pour plusieurs conditions de luminosité.

ENTRETIEN DES LENTILLES ET DE LA MONTURE
Faites attention à ne pas endommager le masque ou à rayer la lentille. Évitez de manipuler ou de frotter la lentille lorsqu'elle est mouillée car elle est plus susceptible de se rayer. Essuyez doucement la lentille avec un chiffon doux pour éliminer l'excès d'humidité. Lorsque la lentille est sèche, polissez doucement avec un chiffon doux pour enlever les taches.
• La lentille ne doit être nettoyée qu'avec de l'eau. Le verre ou d'autres nettoyeurs chimiques peuvent endommager le revêtement de la lentille.
• Ne placer pas la lentille face vers le bas. Si la lentille est rayée, fissurée ou présente d'autres dommages pouvant nuire à la vision, la lentille doit être remplacée.
• Conserver le masque dans une température sèche et modérée. Assurez-vous de conserver à l'abri du soleil ou de la chaleur.
• Les lunettes et la Skibrille doivent être inspectées avant chaque utilisation. Si la lentille ou le cadre est endommagé, le remplacement est fortement recommandé.

VORSICHT
Ces lunettes ont été conçues pour pratiquer le VTT. Le cyclisme ou pour une utilisation de loisirs uniquement. Ces lunettes ne sont pas un produit de sécurité. Elles protègent contre les rayons UV, le vent et l'humidité uniquement. Ce produit n'a pas été conçu pour protéger le porteur contre un éventuel impact avec un objet dur.

HOW TO SELECT THE RIGHT LENS

Our Radke lenses are available in a wide variety of tints, colors and finishes to provide maximum performance and style in almost any light condition.


FILTER CATEGORY	DESCRIPTION	USAGE	SYMBOL
0	LIGHT TINT SUNGLASSES	Very limited reduction of sunglare	IEC 60417-5955
1		Limited protection against sunglare	ISO 7000-2948
2	GENERAL PURPOSE SUNGLASSES	Good protection against sunglare	ISO 7000-2949
3		High protection against sunglare	ISO 7000-2950
4	VERY DARK SPECIAL PURPOSE SUNGLASSES, VERY HIGH SUNGLARE REDUCTION	Very High protection against extreme sunglare, e.g. at sea, over snowfields, on high mountains, or in desert	ISO 7000-2951

Visit wildhornoutfitters.com for more information and a full selection of available lens colors for various light conditions.

DUAL MODE FRAME / LENS EXCHANGE

We designed our Radke eyewear with a unique interchangeable frame design that allows you to quickly go from full frame to open frame in a snap:

- To remove the base frame, while securely holding the upper frame, pull down at the thickest corner portion of the lower frame (1). Once separated, repeat on the opposite corner. With both attachment points freed at the corners, pull straight down on the frame/nose piece to fully remove.
- Lens should be cleaned with water only. Glass or other chemical cleaners may damage the lens coating.
- Do not place lens face down. If the lens is scratched, cracked or has any other damage that impairs vision, the lens should be replaced.
- Store in dry, moderate temperature. Be sure to store away from excessive prolonged exposure to sunlight or heat.
- The eyewear should be inspected before each use. If there is any damage to the lens or frame, replacement is strongly suggested.



CARE & CLEANING:

Use care to avoid damaging the frame or scratching the lens. Avoid handling or rubbing the lens when wet as it is more susceptible to scratching. Gently blot the lens with a soft cloth to remove excess moisture. When the lens is dry, softly polish with the included storage bag or soft cloth to remove any smudges.

- To exchange the lens (with base frame removed) simply hold the upper frame firmly while pulling away the lens working from one corner to the other until it is fully removed. Replace with your desired lens in the opposite motion, again, working from edge to edge of the lens frame until fully secure. You will feel the lens engage and snap into place at each connection point. After the replacement lens has been installed, gently pull at the base of the lens to ensure it is fully secure. Once secured, attach preferred base frame/nose piece and you're ready to ride!

*FOR WILDHORN PATENT INFORMATION
VISIT: WILDHORNOUTFITTERS.COM



WARNING

This eyewear is intended for mountain bike, cycling or casual use only. This is not manufactured as a safety product. It offers protection from UV rays, wind, and moisture only. This product is not intended to and will not protect the wearer from an impact with hard objects.

- Not for direct observation of the sun
- Not for protection against artificial light sources, e.g. solaria
- Not for use as eye protection against mechanical impact hazards
- Not suitable for driving in twilight or at night



This product bears the CE mark showing that this product fulfills the certification requirement: EN ISO 12312-1:2013+A1:2015

MADE IN CHINA



WILDHORN®

WILDHORN OUTFITTERS
11845 South 700 East Suite 200,
Draper, UT 84020

RADKE
PERFORMANCE EYEWEAR