



Watershot® for iPhone® 4/4S
 ‘On, In, Under Water - Capture it with Watershot’



Watershot Inc.®
 11211 Sorrento Valley Road, Suite O
 San Diego, CA 92121

858.678.8552
 support@watershot.com
 www.watershot.com



Introduction

Watershot Inc.®, makers of the top underwater camera housings in the motion picture industry, introduces the purpose-built underwater camera housing for the iPhone – designed and developed for the extreme abuses of water sports. This is no basic case, the Watershot for iPhone is a multi-feature housing specifically made to optimize photo and video capabilities for those who have traded their digital cameras for the simplicity of their smart phone. The unit comes complete with a glass lens port and black rubberized baffle, custom app for imaging optimization and social media sharing, lens and filter ready, with a smart, yet robust & simple mounting system. Able to withstand 50 meters of depth (165 feet), the iPhone is fully suspended within the housings ensuring that the phone and screen are effectively shielded from wear, tear, shock and pressure. The Watershot is a serious tool, yet seriously fun.

Go to www.watershot.com for more information, FAQs, instructional videos, product accessories, etc.

Important Safety Instructions:



1. Read and follow the instructions in this manual.
2. Perform recommended test and checks.
3. Do not use the housing beyond the rated depth rating 50m/165ft
4. After each use the housing should be soaked (20min in fresh water), micro fiber cloth dried, then air dried with the housing open.
5. Always follow installation and removal process per the manufacturers instructions.
6. Replace o-ring(s) that are damaged, worn, stretched or broken.
7. Apply o-ring lubricant only when necessary, a light thin film is all that is needed.
8. If cracks, deformation, or other damage is observed – DO NOT USE.
9. Keep away from heat sources.
10. iPhone may overheat (and shut off) if installed in the housing and exposed to prolonged direct sun exposure.
11. Contains small parts which may be a choking hazard. Not suitable for children under 3 years old.
12. Watershot is not liable for damage to contents.
13. Desiccant pack is provided, use if lens fogging occurs (due to condensation within the housing which may be caused by high relative humidity when loading your iPhone). Place the desiccant pack into the housing (place pack flat in the front housing between the ribs below the iPhone) and keep the housing closed for at least 5 minutes before going into the water. Visit www.watershot.com for additional details and instructions for installing the desiccant into the housing.

Initial Waterproof Test Instructions:

Perform this test process prior to use.

1. Inspect the Watershot for iPhone housing and ensure it is contaminant free and appears in new condition.
2. Confirm that the seals are in good condition. Replace seals if they are loose, worn, cut, or broken.
3. Test buttons. All buttons should return to original position after being depressed.
4. Open housing by sliding the lock to the unlocked position and pressing the latch open.
5. Place a tissue or piece of paper inside the housing.
6. Close the housing, ensuring that the latch fully closes and locks.
7. Submerge the housing in water for 5-10 minutes.
8. Remove the housing, dry it, and then open it.
9. Check to ensure the tissue or paper is dry.
10. Do not use if water is found inside the housing. Contact Watershot support.

It is the user's responsibility to properly test, use, care for, and store the product.

Installing your iPhone:

Prior to installing your iPhone, ensure safety and initial testing instructions have been read and followed!



1. Open housing by sliding the lock to the unlocked position and pressing the latch open. Then pull open the hinged clear back cover.



2. Place iPhone into the housing so that the iPhone camera lens aligns with the black colored lens shroud on the housing. The edges of the iPhone should rest securely within the black rubber vibration isolation bumpers.

Installing your iPhone (cont.):



3. Close the clear hinged lid until the outer o-ring seal is fully seated into the housing.



4. Swivel the latch closed (so that it hooks onto the lid) and press until the latch snaps closed and the lock slides into the "locked" position.
5. Visually inspect the seal to ensure you can see good contact between the seal and housing around the full circumference of the housing.

APP installation Instructions:


1. Download the "Watershot for iPhone" APP from the App Store or iTunes.
2. Install the APP onto your iPhone.
3. Drag the "Watershot for iPhone" APP onto your iPhone "home" screen in the bottom right position (see below).



For more details on installing and using the APP, go to www.watershot.com for additional instructions and online tutorials.

Using your Watershot for iPhone:

1. Prior to installing your iPhone into the housing, change your General setting on your iPhone so that the "Auto-Lock" feature is set to "Never."
2. Install your iPhone into the housing per the provided installation instructions.
3. Press the "HOME" button.
4. Press "Touch Screen Button 1" to open the Watershot for iPhone APP (APP icon must be placed in proper location on your iPhone home screen). This will open the APP.
5. Once the APP is loaded, you will be in "CAMERA MODE."



Using your Watershot for iPhone (cont):

While in CAMERA Mode:

1. Press 'Touch Screen Button 1' to toggle between photo and video mode.
2. Press 'Touch Screen Button 2' to take picture if in photo mode (or start/stop recording if in video mode).
3. Press 'Touch Screen Button 3' to switch to "PLAYBACK MODE."
4. Hold Down 'Touch Screen Button 1' to turn on/off compass feature.
5. Hold Down 'Touch Screen Button 3' to open menu for changing settings and operating features within CAMERA MODE.
6. Hold Down 'Touch Screen Button 2' to place the APP in SLEEP mode.

Using your Watershot for iPhone (cont):

While in PLAYBACK Mode:

1. Press 'Touch Screen Button 1' scroll forward thru the photos/videos you have taken.
2. Press 'Touch Screen Button 2' scroll backward thru the photos/videos you have taken.
3. Press 'Touch Screen Button 3' to switch to "CAMERA MODE."
4. Hold Down 'Touch Screen Button 3' to open menu for posting your image/video to social media sites (Facebook, Twitter, etc.)
5. Hold Down 'Touch Screen Button 2' to place the APP in SLEEP mode.

Note: Additional APP features can be accessed when the iPhone is not in the housing. Press the "Watershot" logo to access features like: Tutorials, Action Camera Settings, Album, Services, and Info. Visit www.watershot.com to view online tutorials with details about how to utilize all the APP features and tools.

WARRANTY

Watershot Inc®. ("Company") warranty obligations for the Company product(s) you have purchased ("Product") are limited to the terms set forth in this document as well those set forth in the Warranty section of the company website if published. Company warrants: (i) if the Guidelines for Appropriate Use (GAU) are followed the Product will perform substantially in accordance to the specifications furnished by Company; and further warrants: (ii) the Product against substantial defects in materials and workmanship under normal use for a period one (1) year from the date of original purchase ("Limited Warranty"). This limited warranty is non-transferable and covers only the original end purchaser. An original or copy of the sales receipt from the original sales retailer or Company website and warranty card on file with Watershot is required for one year coverage. This limited warranty does not cover products purchased through non-authorized dealers and/or online auction websites. Non-authorized dealer receipts and/or online sales auction confirmations are NOT accepted for warranty verification. Warranty claims must be made directly to the Company. No warranty either expressed or implied will be extended to iDivesite or iPix camera housings purchased either inside or outside the United States and its territories.

Exclusions and Limitations

Company's limited warranty applies only to the Product. The warranty does not apply to any non-Company product, even if packaged or sold with the Product. This warranty applies only to the normal use of the Product. This warranty does not apply to damage caused by accident, abuse, misuse, force majeure, or modification of the Product.

Sole and Exclusive Remedy

Your sole and exclusive remedy for a breach of this limited warranty, and Company's sole and entire liability is, at Company's option, to repair or replace the defective Product or refund the purchase price of the defective Product within thirty (30) calendar days of the date of purchase. Repair or replacement (including parts, labor and shipping costs) shall be made at Company's expense. Company reserves the right to send you a replacement product that is the same or of a similar style or a equivalent substitute. Replacement products will be furnished only on an exchange basis. Replacement products are warranted as above for the remainder of the original applicable Product warranty period.

Warranty Disclaimers

EXCEPT AS EXPRESSLY SET FORTH ABOVE IN THIS LIMITED WARRANTY, THE PRODUCT IS PROVIDED ON AN "AS IS" BASIS AND THE COMPANY MAKES NO OTHER EXPRESS OR IMPLIED WARRANTIES TO THE EXTENT PERMITTED BY LAW AND SPECIFICALLY DISCLAIMS AND EXCLUDES ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IF SUCH DISCLAIMER OF ANY IMPLIED WARRANTY IS NOT PERMITTED BY LAW, THE DURATION OF ANY SUCH IMPLIED WARRANTIES IS LIMITED TO THE DURATIONS SET FORTH IN THIS LIMITED WARRANTY. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES OR LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY MAY LAST, SO SUCH LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION.

Limitation of Liability

IN NO EVENT SHALL COMPANY, ITS DISTRIBUTORS OR SUPPLIERS BE LIABLE TO YOU OR ANY THIRD PARTY FOR ANY INDIRECT, INCIDENTAL, CONSEQUENTIAL, SPECIAL, EXEMPLARY OR PUNITIVE DAMAGES ARISING OUT OF THE USE OF THE PRODUCT, INCLUDING, WITHOUT LIMITATION, PROPERTY DAMAGE, LOSS OF VALUE OF THE PRODUCT OR ANY THIRD PARTY PRODUCTS THAT ARE USED IN OR WITH THE PRODUCT, OR LOSS OF USE OF THE PRODUCT OR ANY THIRD PARTY PRODUCTS THAT ARE USED IN OR WITH THE PRODUCT, EVEN IF COMPANY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. COMPANY HAS NO LIABILITY FOR ANY DAMAGE OR DESTRUCTION TO CONSUMER ELECTRONICS DEVICES OR OTHER PERSONAL PROPERTY THAT ARE IN THE PRODUCTS, INCLUDING, WITHOUT LIMITATION, LAPTOPS, CELLULAR PHONES, OR OTHER HANDHELD DEVICES, OR ANY LOSS OF DATA CONTAINED IN THE FOREGOING DEVICES, ETC. NOTWITHSTANDING ANY DAMAGES THAT YOU MIGHT INCUR FOR ANY REASON WHATSOEVER (INCLUDING, WITHOUT LIMITATION, ALL DAMAGES REFERENCED HEREIN AND ALL DIRECT OR GENERAL DAMAGES IN CONTRACT, TORT (INCLUDING NEGLIGENCE OR OTHERWISE), THE ENTIRE LIABILITY OF COMPANY AND ANY OF ITS DISTRIBUTORS AND/OR SUPPLIERS SHALL BE LIMITED TO THE AMOUNT ACTUALLY PAID BY YOU FOR THE PRODUCT. SOME STATES AND/OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU.

Obtaining Warranty Service

If you wish to make a claim under this warranty with respect to the Product, please e-mail support@watershot.com with the following information:

1. Attach photocopy of original purchase receipt or packaging slip.
2. Provide product SKU.
3. Provide purchase date.
4. Brief description of problem (under 500 words)
5. A telephone number and e-mail address at which you can be reached during normal business hours.
6. All of the above information is required before a warranty claim will be accepted. Once Company validates your claim, we will issue you an RMA (Returned Merchandise Authorization) receipt number and shipping information from support@watershot.com.



Copyright Notice

This owner's manual is copyrighted, all rights reserved. It may not, in whole or in part, be copied, photocopied, reproduced, translated, or formed into any electronic format without prior consent in writing. Watershot is a registered trademark of Watershot Inc.. Apple, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. Apple is not responsible for the operation if this device or its compliance with safety and regulatory standards. Watershot products are protected by Pending US Patents.