

PRO MAX GROW X

It's better than the sun by ECO-LITE



INSTALLATION GUIDE

- We recommend using included Ratchet Rope to hang your Pro Max Grow Fixture for maximum strength and safety.
- Secure each fixture power cable, to ensure no loose cords or low hanging power cords.
- Follow local building code requirements when installing Pro Max Grow fixtures.
- Mounting height from canopy can vary, we recommend starting at 12-15 inches below the center of the fixture.



DO NOT LOOK AT THE LIGHT, AS EYE CONTACT WILL CAUSE DAMAGE TO THE EYE.
DO NOT OPEN PRO MAX GROW FIXTURES, AS THE WARRANTY WILL VOID.
DO NOT SWITCH OUT OR REPLACE PRO MAX GROW COMPONENTS, AS WE DO NOT USE ANY "SHELF" COMPONENTS

Call Pro Max Grow at 800-345-9652 if you experience any problems or have any questions.

WARNING

- Make sure to keep all flammable material away from your Pro Max Grow fixture.
- Do not hang the fixture by the power cord.
- Wear safety glasses and gloves when installing fixture.
- Recommended free space around fixture is 1-2 inches.
- Only use grounded plugs with 10amp rating.
- Do not look at the light source.
- Wait until install is complete to power on the fixture.
- Pro Max Grow recommends using common sense when installing our fixtures.



33 Rockland Park Avenue Tappan, New York 10983 USA
Telephone: (800) 345-9652 FAX: (845) 365-9777
<http://www.promaxgrow.com>