

MAY 9, 2014, 24157, R2

FALL HAZARD - to prevent death or serious injury, always keep child within arm's reach. Read all instructions before use of the changing table.

KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE USE.

Inspect the changing table periodically. **Do not** use the changing table if it is damaged or broken. Contact Delta Children's Products with any questions.

Tighten all loose screws and bolts before each use.

The maximum recommended weight of the child is 30lbs for the changing table.

Use only the pad provided by Delta Children's Products.

NOTES ON ASSEMBLY:

-During the assembly process whenever using screws or bolts, check each by placing the screw/bolt on the diagram of the item which is drawn actual size and design. Be sure to use the proper size and shape specified in the instructions.

-To assemble this unit you may be required to place the unit on it's side and face. It is strongly

recommended that assembly is done on a soft, non-abrasive surface to avoid damaging the finish.

NOTES ON USE:

Keep children and others safe by following these simple rules:

- Do not allow any child to play on furniture
- Do not allow climbing on any piece of furniture.
- Do not allow hanging from any piece of furniture.
- Always monitor your child's activity when in the nursery.

NOTES ON CARE AND MAINTENANCE:

- **Do not** scratch or chip the finish.
- Inspect the product periodically, contact Delta Children's Products for replacement parts or questions.
 Do not store the product or any parts in extreme temperatures and conditions such as a hot attic or a damp, cold basement. These extremes can cause a loss of structural integrity.


-To preserve the luster of the high quality finish on your product, it is recommended to place a doily or felt pad under any items you place on the finish.


-Clean with a damp cloth, then a dry cloth to preserve the original luster and beauty of this fine finish. -**Do not** use abrasive chemicals.


-Do not spray cleaners directly onto furniture.

-Lift slightly when moving on carpeting to prevent leg breakage.

-Use of a vaporizer near furniture will cause wood to swell and finish to peel.









Section 1: Changing Table Assembly Step 2 Parts and tools required to complete step.


Lay the Left Side on the floor, rails up. Slide the Top Shelf (Part H) in the grooves on the Middle Front Rail and Upper Back Rail, into the groove on the Left Side, Slide (2) Bottom Shelves (Part J) in the grooves on the Bottom Rails, into the grooves on the Left Side as shown.




Section 1: Changing Table Assembly Step 3





Attach (1) Right Side (Part B) to the assembly from step 2 with (3) Φ4x30 mm Metal Pins (Part P) and (8) M6x50 mm Bolts (Part M) using the M4 Allen Wrench as shown.




Section 1: Changing Table Assembly







Align the hole in the end of the strap of the Restraint Harness (Part L) with the hole in the Top Shelf. Insert (1) M6x25 mm Bolts (Part T) through a Nylon Washer (Part R), the Restraint Strap and the hole in the Shelf. Add (1) Nylon Washer (Part R) with a Nut (Part S). Hold the Nut with a Pliers or Adjustable Wrench. Repeat with the other side of the strap as shown.





Section 1: Changing Table Assembly Step 7 Parts and tools required to complete step.

K. Changer Pad x 1

From Step 6

Place the Changer Pad (Part K) onto the Top Shelf (Part H) on top of the attached Strap from step 6, Be sure the buckle on the strap is over the Pad as shown.







Consumer Care: www.DeltaChildren.com Delta Children's Products 114 West 26th Street New York, NY 10001 Tele.212-645-9033

Warranty: This Delta product is warranted to be free from defects for a period of 90 days from the date of purchase under normal use. This warranty extends only to the original retail purchaser and is valid only when supplied with proof of purchase, or if received as a gift, when the registration is on file with Delta.

To register your product for important safety alerts and updates to your product please visit **www.DeltaChildren.com**

Please do not return this item to the store before contacting us about missing parts or with any questions.

To report a problem, please log on to **www.DeltaChildren.com** and click the Consumer Care Tab, or contact us by phone at (212) 645-9033.

In the event that you need to contact our customer service department please have the Style Number and Lot Number available. Use the space below to make note of those numbers. They can be found on the label on the Top Shelf.

STYLE No: 7542		A
	COLOR	REV FTY
Lot No. :		
Pack Date:		
Date of Purchase:	(you shou	Ild also keep your receipt)