



User's Guide

Baby Monitor

28001-114
28101-114



WARNING: STRANGULATION HAZARD

WARNING: STRANGULATION HAZARD. Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3ft (0.9 m) away).

Adult assembly is required. Keep small parts away from children when assembling. Failure to follow these warnings and the assembly Instructions could result in serious injury or death.

Keep this instruction manual for future reference.

This device is designed only to monitor the sounds of your child.

It will not alert you to your child's silent activities or movement.

When using the monitor, you must still provide the supervision necessary for the continued safety of your child. This product is not designed or intended for use as a medical monitor. Always be sure that both the transmitter and receiver are working properly and are within range of each other.

⚠ WARNING: This product is not a toy. Do not allow children to play with it. Keep out of reach of children.

DO NOT place the Baby Unit or its cord within your child's reach. Do not put the Baby Unit inside a crib or playard.

Use ONLY with 100-240 volt AC electrical outlets.

Allow for proper ventilation when units are in use.

Do not cover the Nursery Unit or Parent Units with any object such as a blanket. Do not place it in a drawer or in any location which would muffle the sound or interfere with the normal flow of air inside a crib or playard.

DO NOT immerse any part of the Nursery Unit or Parent Units in water. Clean only with a dry cloth.

DO NOT place unit near water and moisture. Do not use the Nursery Unit outdoors. Do not use the Baby Unit near possible wet areas, such as a bathtub, shower, wash basin, sink, laundry tub, swimming pool, wet basement, etc.

Keep Baby Unit away from heat sources, such as fireplaces, radiators, stoves, and TVs or other appliances. Heat can damage the case or electrical parts.

DO NOT use the Nursery Unit if:

- The adapter cords or plugs have been damaged.
- The unit has been exposed to liquids.
- Unit has been dropped or is damaged.

DO NOT OPEN THE NURSERY UNIT OR PARENT UNITS OR ADAPTERS.

No user-serviceable parts inside. Risk of electrical shock, fire or death. case or electrical parts.

Battery Safety Information:

In exceptional circumstances, batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Do not mix old and new batteries or batteries of different types: Alkaline, standard (carbon zinc) or rechargeable (nickel-cadmium).
- Insert batteries as indicated inside battery compartment.
- Remove batteries during long periods of non-use. Always remove exhausted batteries from the product. Dispose of batteries safely. Do not dispose of product in a fire. The batteries inside may explode or leak.
- Never short-circuit the battery terminals.
- Use only batteries of the same or equivalent type as recommended.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the product before charging.
- If removable, rechargeable batteries are used, they are only to be charged under adult supervision.

FCC Statement:

⚠ WARNING: Modifications not authorized by the manufacturer may void user's authority to operate this device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.


However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- Look for the FCC ID on the bottom of the Nursery Unit and inside the Battery compartment on the Parent Unit.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Parts

Parent Unit





Model 28001 - 1 Unit
Model 28101 - 2 Unit

AC Adapter




Model 28001 - 2 Unit
Model 28101 - 3 Unit

Parent Unit (Back View)




Baby Unit


Battery Installation



1. Turn Belt strap up.



2. Push down back panel and slid down.



3. Insert 3 AAA batteries.
(Batteries NOT included)


When setting up the Parent unit. Remove the backing and insert the batteries for mobile use. When using the ac adaptor remove the batteries for safety purposes listed in the Adaptor section. Once the parent unit has a power source. Press and hold the power button for 3 seconds. The green power light will blink on. The green light will blink green every 3 second indicating it is on. If the red link light is blinking, that means either your device isn't linked, or the baby unit has lost power and should be placed to an appropriate power source.

Using AC Adapter


The Baby Unit(s) can use 3-AAA (1.5V-LR03) batteries (NOT INCLUDED) or standard AC household current that comes with the unit. The Parent Unit uses the standard AC household current that comes with the unit.

REMOVE Batteries from Parent unit when using AC Adaptor


- To use AC adapters, plug the connector on the cord into the AC adapter jack on the side of the Parent Unit and the side of the Baby Unit. Then plug adapter into a standard wall outlet.
- Use **ONLY** the adapters included with the unit. Do not use these adapters with other equipment under any circumstances.
- If units do not work, check that AC adapters are plugged into working outlets.



INSTRUCTIONS




Turning on the unit


A. To power on. Push down and HOLD  button for 3 seconds.
For both the **Parent** and **Baby Unit**

B. Choose a proper location with easy access to a power outlet.

C. Place **Baby Unit** where you want to monitor your baby.



Turning off the unit

To power off. Push down and HOLD  button for 3 seconds.
For both the **Parent** and **Baby Unit**



Delta Childrens Products Corp.

114 West 26th Street
New York, NY 10001
1-800-377-3777