

MEASURING YOUR FINGER

Your ring should fit your finger comfortably; snug enough so that it will not fall off, but loose enough to slide over your knuckle.

Finger size changes depending on the time of day and the weather. For best results measure your finger size:

- 1. At the end of the day and when your fingers are warm (Fingers are smaller in the early morning and when cold.)
 - 2. Measure finger size 3 to 4 times to eliminate an erroneous reading.

Avoid using string or paper to measure ring size as these materials can stretch or twist, yielding an inaccurate measurement.


TIPS FOR BUYING THE RING AS A SURPRISE

Ask your significant other's friends or mother if they know her finger size.

Borrow one of your significant other's rings (from the correct finger) and use the ring measurements above to determine its size.


TINYWBLING

HOW TO DETERMINE YOUR RING SIZE




MEASURE CURRENT RING

- 1. Select a ring that properly fits the intended finger.
 - Engagement and wedding rings are traditionally worn on the ring finger on the left hand in the United States.
- Place the ring over the circles below, matching the inside edge of the ring to the circle nearest in size. This measurement refers to the inside diameter of the ring.
- If the ring falls between two sizes, order the larger size.



MEASUREMENTS MATCH THE INSIDE EDGE OF THE RING





INTERNATIONAL RING SIZE CHART

United States

China

UK & Australia

Singapore

Hong Kong Switzerland

ircumference

Diameter

(mm)	(mm)	Europe	UK & Australia	& Canada	Cnina	& Japan	Hong Kong	Switzeriand
44.2	14.1	44	F1⁄2	3	6	4	6	4
44.8	14.3	45	G			5		51⁄4
45.5	14.5		G1/2	31/2	7		7.5	
46.1	14.7	46	Н			6		61/2
46.8	14.9	47	H½	4	8	7	9	
47.4	15.1		I		9			7¾
48.0	15.3	48	l½	41/2		8	10	
48.7	15.5		J					9
49.3	15.7	49	J½	5	10	9	11	
50.0	15.9	50	K					10
50.6	16.1		K½	51/2	11	10	12	
51.2	16.3	51	L					11¾
51.9	16.5	52	L1/2	6	12	11	13	12¾
52.5	16.7		М		13	12		
53.1	16.9	53	M½	61/2		13	14.5	14
53.8	17.1		N		14			
54.4	17.3	54	N½	7		14	16	151/4
55.1	17.5	55	0		15			
55.7	17.7		O1⁄2	71/2		15	17	161/2
56.3	17.9	56	Р		16			
57.0	18.1	57	P1/2	8	17	16		17¾
57.2	18.2						18	
57.6	18.3		Q					
58.3	18.5	58	Q1/2	81/2	18	17	19	
58.9	18.8	59	R					19
59.5	19.0		R1/2	9	19	18	20.5	
60.2	19.2	60	S		20			201⁄4
60.8	19.4	61	S1/2	91/2		19	22	
61.4	19.6		Т		21			211/2
62.1	19.8	62	T1/2	10		20	23	
62.7	20.0		U		22	21		
63.4	20.2	63	U1⁄2	101/2		22	24	22¾
64.0	20.4	64	V		23			
64.6	20.6		V1/2	11		23	25	
65.3	20.8	65	W		24			25
65.9	21.0	66	W½	111/2	25	24	26	
66.6	21.2		X					
67.2	21.4	67	X1/2	12	26	25	27.75	271/2
67.8	21.6		Υ					
68.5	21.8	68	Z	121/2		26		28¾
69.1	22.0	69	Z1/2					
69.7	22.2	70		13		27	30	
70.4	22.4		Z+1					
71.0	22.6		Z+2	13½				
								•