


CTECHi

300W Foldable Solar Panel



Contact us:
support@ctechi.com.cn

CTECHI

Shenzhen CTECHI Technology Co., Ltd.

Add: 601.701.801, Building 5, Jiada Industrial Park, Honghu East Road, Yanchuan Community, Yanluo Street, Baoan District, Shenzhen City, PRC

TEL: 400-90-18650

WEB: www.ctechipower.com

Email: support@ctechi.com.cn



CONTENTS

English 01~05

Chinese 06~08


About Product

Thank you for purchasing the CTEChi 300W solar panel.


This product uses the sunlight to power your devices whenever and wherever you need it. Designed to the highest technical specifications and standards, this product delivers loads of free green energy.

Please read this manual carefully before use and keep it in a safe place for future reference.

Packing List



300W Foldable Solar Panelx1




User Manual x1

Specifications

Model	SP-300
Peak Power	300W
Cell Conversion Rate	23%
Charging Interface	MC4 output
Unfolded Dimensions	1775*1060*4mm
Folded Dimensions	1060*630*30mm
Operating Temperature	-40°C~85°C
Weight	12kg

How to use

1. Take the solar panel out of the bag, unfold the solar panel.
2. Put the bag vertically, then fix the solar panel on the bag with a mountaineering buckle, adjust the angle, and then connect the portable power station and other electronic products for charging.
3. When charging, keep the electronic products ventilated and place it under the solar panel, in the pocket of the solar panel or in a cool place.



How to charge your phone/USB device?

1. Expanding solar panel, to get more sunlight, please try to keep the solar panel at 90° angle to the sunlight.
2. Connect the device to the output using a USB or DC cable. Suitable for charging a variety of Apple and Android phones, tablets, some laptops, portable power stations and other devices.
3. Keep the charger ventilated. Place it under the solar panel, in a solar panel pocket or in the shade to avoid overheating.

FAQ

1. Why can't the solar panel charge?
 - A. Please check whether the output cable or plug is ok. Try replugging the cable or replacing it with a new one.
 - B. Please check whether the sunlight is directly on the solar panel, reorient the solar panel to ensure the solar panel can get enough sunlight.
 - C. Please check the surface of the solar panel for stains or clogs. You can use a cloth to clean the surface of the solar panel to avoid clogging the solar panel.
2. Why are devices charging slowly?
 - A. Please check whether it is cloudy or rainy? Bad weather impairs the efficiency of the solar cells.
 - B. Please replace the cable with a new one or use it in a sunny environment.
 - C. Please do not leave your electronic device in the sun or in an overheated environment for a long period of time.
3. Does the solar panel work when the sky is cloudy?

Yes, but charging efficiency will be reduced, resulting in longer charging times.

Notes

1. Place the solar panel in direct sunlight and make sure that no other objects cover the solar panel.
2. Connect the solar charger to the appropriate cable or certified power cable for charging.
3. To get the maximum amount of energy from the sun, orient the solar panel perpendicular to the sunlight.
4. Do not leave your cell phone and tablet in direct sunlight for a long time as it may cause overheating and damage.
5. Do not pierce, throw, drop, bend or modify this product.
6. Do not let children play with this product.

Warranty

1 year from the date of purchase (defects caused by personal abuse or other natural disasters are excluded from the warranty).

Please provide proof of purchase during the warranty.

Return and exchange warranty instructions


Warranty card	
Model:	SP-300
Date of purchase:	
Warranty period:	1 year from date of purchase
Name:	
Address:	
E-mail:	
Vendor Name:	

CTECHi Customer Service
Email :support@ctechi.com.cn

关于产品

欢迎您购买使用我司300W太阳能折叠板产品。此产品可利用太阳光,随时随地为您的设备供电。本产品按照最高技术规范 and 标准设计,它可提供充足免费绿色能源。请在使用前仔细阅读这些说明,然后将其存放在安全的地方以备将来参考。

包装内容



300W太阳能折叠板一块




使用说明书一张

技术规格如下

型号	SP-300
峰值功率	300W
电池片转换率	23%
输出	MC4 输出
展开尺寸	1775*1060*4mm
折叠尺寸	1060*630*30mm
工作温度范围	-40°C~85°C
产品净重	12kg

使用方法

1. 将太阳能板从包装袋里拿出来，打开折叠太阳能板。
2. 将包装袋竖放，然后用登山扣将太阳能板固定在包装袋上，调整好角度，然后连接储能设备等。
3. 充电时保持设备通风。将其放置在太阳能电池板下方、太阳能电池板的口袋中或阴凉处，以避免过热。



常见问题和解决方案

1.为什么太阳能板无法充电?

- A.输出线材或插头是否正常,重新插拔或更换新的线材。
- B.阳光是否直面太阳能板,请重新调整太阳能板的方向,确保太阳能板充分地接收阳光。
- C.太阳能板表面是否有污迹或遮挡物,用布料清洁板面,避免有障碍物遮挡太阳能板。

2.为什么电子设备充电慢?

- A.确认使用环境及天气是否多云或是下雨天?天气不好使太阳能板低功率发电。
 - B.请更换新线材或者在阳光充足的环境下使用。
 - C.请勿将电子设备置于阳光下或长时间过热的环境中。
- 3.如果是阴天,太阳能板还能用吗?
可以,但是充电效率会降低,导致充电时间延长。

警告

- 1. 将太阳能板放在直射的阳光下,不要让其他物体覆盖太阳能板。
- 2. 将太阳能充电器连接相应匹配的线材或通过认证的电源线进行充电。
- 3. 为了获得最大的太阳光能量,请调节太阳能板垂直于阳光的方向。
- 4. 请勿将手机和平板电脑长时间放在阳光直射的地方,否则可能过热造成损坏。
- 5. 请勿刺穿,投掷,掉落,弯曲或改装本产品。
- 6. 请勿让儿童玩此产品。

质保

自购买之日起,提供1年质保期(由于个人使用不当或是其他自然灾害导致不良,不在质保范围内)

质保期和质保范围内,产品售后服务需提供购买凭证。

