
# WindFall® STAND



Secure Stand for iPad Pro 12.9-inch (3rd Gen)

Assembly & Installation





Compatible with:

iPad Pro 12.9-inch (3rd Gen)


#### Limited Warranty

Heckler Design warrants your product to be free from defect in material and workmanship for a period of two years from the original date of purchase. Electronic components are warranted to be free from defect for a period of one year from the original date of purchase. If you discover a defect, please contact service@hecklerdesign.com. Heckler Design will repair, at our discretion, using new or refurbished components. If repair is not possible, Heckler Design will replace the item.





Optional: Kensington NanoSaver Keyed Laptop Lock (sold seperately)




Optional:
PivotTack (sold seperately)



Optional:

PivotTable (sold seperately)





Optional: Kensington ClickSafe Cable Lock (sold seperately)




### 1 Select then install feet
















### **Option: Remove original screws**







### **Install security screws**




### 2 Loosen and remove screws




### 3 Remove right-hand tablet bracket and cord securer




#### 4 Install the iPad Pro




## 5 Route your USB-C cable and reinstall right-hand tablet bracket



### 5 Fasten cord securer



### 6 Tighten all screws



### 7 Done

