



Wireless Controller For P4

Getting Started


- Make sure you read this guide,before using the controller.
- Reading this guide will help you learn to use the controller.
- Store this guide safely so that you can use it in the future.



User Manual

Brief Introduction:

- * Designed for P4/P4 Pro/P4 Slim
- * Vibration function
- * Accurate, multi-functional motion control
- * Improved ergonomics providing a more comfortable grip
- * The 3.5mm stereo headset jack can connect with headset and microphone, allowing Users to receive and transmit audio at the same time.



Lighting mode switching operation

First press and hold the Right joystick (R3), then click the SHARE button once to turn on the light mode (Only hold down R3 and click the SHARE button once to switch the lighting mode.)

Mode 1: Rainbow Light Mode (Press and hold the right joystick (R3) and move the left joystick left/right to switch light colors. Move up to increase brightness and down to decrease brightness.)

Mode 2: Colorful breathing light mode (red, green, yellow, blue, white, purple, indigo)

Mode 3: Random Single Light Mode

Mode 4: Turn off the lights (L3+R3)

Indicator light

Led indicators will enter into breathing light mode if the controller is charging under power off status, and the color is random. The light goes off when controller is full charged.

Different light colors of each controller when several controllers connected to one Console at the same time:

User 1 blue light, User 2 red light, User 3 green light, User 4 pink light.

Stand-by mode: orange light Charge while playing: blue light

Charge while in stand-by mode: orange light, and light goes off when full charged

Controller lose connection: white light

Registering (pairing) the controller


Bluetooth Connection:

- 1) A data-capable USB cable is required to wired connect the controller to P4 console for the first time.
- 2) Press and hold the HOME button, controller's LED light bar will flash
- 3) Once connected successfully, the LED light bar will remain lit, now you can enjoy your controller wired or wirelessly.

After the first pairing, hence you can reconnect the controller to the Console wirelessly via Bluetooth.

One P4 console can only support 4 bluetooth devices at the same time no matter it's connected wired or wirelessly.

According to the requirements of shipping lithium batteries by air, if the voltage of lithium batteries are Over 3.7V, which will be prohibited for shipment to, Therefore, when controller delivered, maybe not work because of the power shortage, at this point, please charge for your controller first.



- 1, Firstly turn on the P4 system
- 2, Connect the controller to the P4 system with the USB cable
- 3, Hold the HOME button to complete device registration.

USB cable (supplied with the P4 system or included in package)

How to set up Turbo function


The turbo button causes the game function assigned to the button to fire in rapid succession, which makes it easier to play arcade or action games.

E.g. Fire 1 bullet when you hit the button once, when turbo is on and you hold down the button, it fires continuously. The following buttons can be set to Turbo mode:


The following buttons can be set to Turbo mode:

(□ / △ / ○ / × / L1 / L2 / R1 / R2 /)

Hold down the button that you want to set to Turbo, then press the Share button one time.




After setting up Turbo mode, you want to cancel this button's Turbo function. Hold down the button, then press the Share button one time.



After controller is powered off, Turbo function will be deactivated

Reset function

When the controller is out of order, which can be reset by poking the reset key with a needle.



Product specification

Type of battery	lithium battery
Battery capacity	1000mAh
Full charge time	≈ 3.5H
Operating voltage	USB DC 5V <350mA
Dimensions	170*115*70mm
Weight	0.22kg

Package contents

- ① Controller ----- 1PCS
- ② 0.8m Charging cable ----- 1PCS
- ③ User Manual ----- 1PCS