

# PowerFLO™ 5800/5900 – 5 Chamber

## Ordering - Model Number Configurator

Select the appropriate order code from each of the designated categories below to build a complete pump model number. **For example: 5930-101A-A38**

	Order Code	
<b>Pump Head</b>	<b>58</b>	5 chambers with 1/2" FNPT ports
	<b>59</b>	5 chambers with quick attach ports
<b>Open Flow</b>	<b>30</b>	3.0 GPM
	<b>36</b>	3.6 GPM
	<b>40</b>	4.0 GPM
	<b>50</b>	5.3 GPM
<b>Motor Configuration</b>	<b>1</b>	lead wires
	<b>2</b>	2-pin connector (5830 & 5930 only)
	<b>3</b>	2-pin connector with on/off switch (5830 & 5930 only)
<b>Pump Type</b>	<b>0</b>	Demand
	<b>1</b>	Bypass
<b>Motor Voltage</b>	<b>1</b>	12 VDC
	<b>3</b>	115 VAC
	<b>4</b>	115 VAC with 4' cord (UL listed)
<b>Pressure Shut-Off</b>	<b>A</b>	30 PSI
	<b>B</b>	40 PSI
	<b>C</b>	45 PSI
	<b>D</b>	50 PSI
	<b>E</b>	60 PSI
	<b>F</b>	70 PSI
	<b>W</b>	90 PSI
	<b>Y</b>	100 PSI
<b>Inlets/Outlets*</b>	<b>A38</b>	3/8" straight hose barb
	<b>A12</b>	1/2" straight hose barb
	<b>A34</b>	3/4" straight hose barb
	<b>E38</b>	3/8" elbow hose barb
	<b>E34</b>	3/4" elbow hose barb
	<b>E12</b>	1/2" elbow hose barb
	<b>T38</b>	T-Fitting– 3/8" hose barb x 3/4" MGHT
	<b>T38G</b>	T-Fitting with 1/4" NPT gauge port– 3/8" hose barb x 3/4" MGHT
	<b>T12</b>	T-Fitting– 1/2" hose barb x 3/4" MGHT
	<b>T12G</b>	T-Fitting with 1/4" NPT gauge port– 1/2" hose barb x 3/4" MGHT
	<b>T34</b>	T-Fitting– 3/4" hose barb x 3/4" MGHT
<b>T34G</b>	T-Fitting with 1/4" NPT gauge port– 3/4" hose barb x 3/4" MGHT	

*\*Quick attach fittings available on 5900 models only)*

