




*Visit our Quick Start Guide at www.playpiper.com/quickstart to find up-to-date instructions and troubleshooting tips for ensuring a successful Piper experience.

Quick Start Guide


1 Charge the Battery Pack & the Speaker

Before you start building your Piper Computer Kit, charge the Battery Pack and the Speaker using the Micro USB Cable provided and your own USB Wall Adapter. This process may take several hours.


a. Insert the Micro USB Cable into the side of the Battery Pack.




b. Connect the Micro USB Cable to your USB Wall Adapter. It may take approximately 6-10 hours for first full charge.



c. Insert the Micro USB Cable into the side of the Speaker.




d. Connect the Micro USB Cable to your USB Wall Adapter. It may take approximately 2-3 hours for first full charge.



2 Build the Computer

Follow the steps provided in the blueprint using the parts and screwdriver included in the kit. You'll need a coin to tighten the screws in steps 5B and 5D.

If you run into issues or have questions, go to www.support.playpiper.com or contact our support at hi@playpiper.com



3 Connect to WiFi & Update

Before getting started, please download the most recent version of our software to get the best experience possible.

Step 1: Connect to Wifi. Press the Wifi icon at the top of the screen. Select your network, and you'll be asked to supply the password.

Step 2: Press the update button at the top right to download the most recent version of our software.

