

Tested Ballast List

Item	Manufacturer	Model	Type	Compatible
1	Philips-Advance	ICN-IP32-N	Instant Start Ballast	✓
2	Philips-Advance	ICN-2P32-N	Instant Start Ballast	✓
3	Philips-Advance	ICN-3P32-N	Instant Start Ballast	✓
4	Philips-Advance	ICN-4P32-N	Instant Start Ballast	✓
5	Philips-Advance	ICN-IP32-SC	Instant Start Ballast	✓
6	Philips-Advance	ICN-2P32-SC	Instant Start Ballast	✓
7	Philips-Advance	ICN-3P32-SC	Instant Start Ballast	✓
8	Philips-Advance	ICN-4P32-SC	Instant Start Ballast	✓
9	Philips-Advance	IOP-1P32-LW-SC	Instant Start Ballast	✓
10	Philips-Advance	IOP-2P32-LW-SC	Instant Start Ballast	✓
11	Philips-Advance	IOP-3P32-LW-SC	Instant Start Ballast	✓
12	Philips-Advance	IOP-4P32-LW-SC	Instant Start Ballast	✓
13	Philips-Advance	IOPA-1P32-LW-N	Instant Start Ballast	✓
14	Philips-Advance	IOPA-2P32-LW-N	Instant Start Ballast	✓
15	Philips-Advance	IOPA-3P32-LW-N	Instant Start Ballast	✓
16	Philips-Advance	IOPA-4P32-LW-N	Instant Start Ballast	✓
17	Philips-Advance	IOPA-1P32-N	Instant Start Ballast	✓
18	Philips-Advance	IOPA-2P32-N	Instant Start Ballast	✓
19	Philips-Advance	IOPA-3P32-N	Instant Start Ballast	✓
20	Philips-Advance	IOPA-4P32-N	Instant Start Ballast	✓
21	Philips-Advance	IOP-1P32-SC	Instant Start Ballast	✓
22	Philips-Advance	IOP-2P32-SC	Instant Start Ballast	✓
23	Philips-Advance	IOP-3P32-SC	Instant Start Ballast	✓
24	Philips-Advance	IOP-4P32-SC	Instant Start Ballast	✓
25	Philips-Advance	IOPA-1P32-HL-SC	Instant Start Ballast	✓
26	Philips-Advance	IOPA-2P32-HL-SC	Instant Start Ballast	✓
27	Philips-Advance	IOPA-3P32-HL-SC	Instant Start Ballast	✓
28	Philips-Advance	IOPA-4P32-HL-SC	Instant Start Ballast	✓
29	Philips-Advance	GOPA-1P32-SC	Instant Start Ballast	✓
30	Philips-Advance	GOPA-2P32-SC	Instant Start Ballast	✓
31	Philips-Advance	GOPA-3P32-SC	Instant Start Ballast	✓
32	Philips-Advance	GOPA-4P32-SC	Instant Start Ballast	✓
33	Philips-Advance	GOP-IPSP32-SC	Instant Start Ballast	✓
34	Philips-Advance	GOP-2PSP32-SC	Instant Start Ballast	✓
35	Philips-Advance	GOP-3PSP32-SC	Instant Start Ballast	✓
36	Philips-Advance	GOP-4PSP32-SC	Instant Start Ballast	✓

Item	Manufacturer	Model	Type	Compatible
37	Philips-Advance	GOPA-1P32-LW-SC	Instant Start Ballast	✓
38	Philips-Advance	GOPA-2P32-LW-SC	Instant Start Ballast	✓
39	Philips-Advance	GOPA-3P32-LW-SC	Instant Start Ballast	✓
40	Philips-Advance	GOPA-4P32-LW-SC	Instant Start Ballast	✓
41	SYLVANIA	QHE 1X32T8/UNV ISL-SC	Instant Start Ballast	✓
42	SYLVANIA	QHE 2X32T8/UNVISL-SC	Instant Start Ballast	✓
43	SYLVANIA	QHE 3X32T8/UNVISL-SC	Instant Start Ballast	✓
44	SYLVANIA	QHE 4X32T8/UNVISL-SC	Instant Start Ballast	✓
45	SYLVANIA	QHE 1X32T8/UNV ISN-SC	Instant Start Ballast	✓
46	SYLVANIA	QHE 2X32T8/UNV ISN-SC	Instant Start Ballast	✓
47	SYLVANIA	QHE 3X32T8/UNV ISN-SC	Instant Start Ballast	✓
48	SYLVANIA	QHE 4X32T8/UNV ISN-SC	Instant Start Ballast	✓
49	SYLVANIA	QHE 1X32T8/UNV ISH-SC	Instant Start Ballast	✓
50	SYLVANIA	QHE 2X32T8/UNV ISH-SC	Instant Start Ballast	✓
51	SYLVANIA	QHE 3X32T8/UNV ISH-SC	Instant Start Ballast	✓
52	SYLVANIA	QHE 4X32T8/UNV ISH-SC	Instant Start Ballast	✓
53	SYLVANIA	QTP 1X32T8/UNV ISL-SC	Instant Start Ballast	✓
54	SYLVANIA	QTP 2X32T8/UNV ISL-SC	Instant Start Ballast	✓
55	SYLVANIA	QTP 3X32T8/UNV ISL-SC	Instant Start Ballast	✓
56	SYLVANIA	QTP 4X32T8/UNV ISL-SC	Instant Start Ballast	✓
57	SYLVANIA	QTP 1X32T8/UNV ISN-SC	Instant Start Ballast	✓
58	SYLVANIA	QTP 2X32T8/UNV ISN-SC	Instant Start Ballast	✓
59	SYLVANIA	QTP 3X32T8/UNV ISN-SC	Instant Start Ballast	✓
60	SYLVANIA	QTP 4X32T8/UNV ISN-SC	Instant Start Ballast	✓
61	SYLVANIA	QTP 1X32T8/UNV ISH-SC	Instant Start Ballast	✓
62	SYLVANIA	QTP 2X32T8/UNV ISH-SC	Instant Start Ballast	✓
63	SYLVANIA	QTP 3X32T8/UNV ISH-SC	Instant Start Ballast	✓
64	SYLVANIA	QTP 4X32T8/UNV ISH-SC	Instant Start Ballast	✓
65	SYLVANIA	QHE 1X32T8/347 ISL-SC	Instant Start Ballast	✓
66	SYLVANIA	QHE 2X32T8/347 ISL-SC	Instant Start Ballast	✓
67	SYLVANIA	QHE 3X32T8/347 ISL-SC	Instant Start Ballast	✓
68	SYLVANIA	QHE 4X32T8/347 ISL-SC	Instant Start Ballast	✓
69	SYLVANIA	QHE 1X32T8/347 ISN-SC	Instant Start Ballast	✓
70	SYLVANIA	QHE 2X32T8/347 ISN-SC	Instant Start Ballast	✓
71	SYLVANIA	QHE 3X32T8/347 ISN-SC	Instant Start Ballast	✓
72	SYLVANIA	QHE 4X32T8/347 ISN-SC	Instant Start Ballast	✓
73	SYLVANIA	QTP 1X32T8/347 ISN-SC	Instant Start Ballast	✓
74	SYLVANIA	QTP 2X32T8/347 ISN-SC	Instant Start Ballast	✓
75	SYLVANIA	QTP 3X32T8/347 ISN-SC	Instant Start Ballast	✓
76	SYLVANIA	QTP 4X32T8/347 ISN-SC	Instant Start Ballast	✓

Item	Manufacturer	Model	Type	Compatible
77	GE	GE-132-MV-N	Instant Start Ballast	✓
78	GE	GE-232-MV-N	Instant Start Ballast	✓
79	GE	GE-332-MV-N	Instant Start Ballast	✓
80	GE	GE-432-MV-N	Instant Start Ballast	✓
81	GE	GE-132-MV-N-DIY	Instant Start Ballast	✓
82	GE	GE-232-MV-N-DIY	Instant Start Ballast	✓
83	GE	GE-332-MV-N-DIY	Instant Start Ballast	✓
84	GE	GE-432-MV-N-DIY	Instant Start Ballast	✓
85	GE	GE232MAX347-N	Instant Start Ballast	✓
86	GE	GE432MAX347-N	Instant Start Ballast	✓
87	GE	GE-132-MAX-N/Ultra	Instant Start Ballast	✓
88	GE	GE-232-MAX-N/Ultra	Instant Start Ballast	✓
89	GE	GE-332-MAX-N/Ultra	Instant Start Ballast	✓
90	GE	GE-432-MAX-N/Ultra	Instant Start Ballast	✓
91	GE	GE-132-MAX-L/Ultra	Instant Start Ballast	✓
92	GE	GE-232-MAX-L/Ultra	Instant Start Ballast	✓
93	GE	GE-332-MAX-L/Ultra	Instant Start Ballast	✓
94	GE	GE-432-MAX-L/Ultra	Instant Start Ballast	✓
95	GE	GE-132-MAX-H/Ultra	Instant Start Ballast	✓
96	GE	GE-232-MAX-H/Ultra	Instant Start Ballast	✓
97	GE	GE-332-MAX-H/Ultra	Instant Start Ballast	✓
98	GE	GE-332-MAX-L/Ultra	Instant Start Ballast	✓
99	GE	GE-432-MAX-L/Ultra	Instant Start Ballast	✓
100	GE	GE-132-MAX-H/Ultra	Instant Start Ballast	✓
101	GE	GE-232-MAX-H/Ultra	Instant Start Ballast	✓
102	GE	GE-332-MAX-H/Ultra	Instant Start Ballast	✓
103	GE	GE-332-MAX-H/Ultra	Instant Start Ballast	✓
104	SUNPARK	U-1/32ISE-HBF	Instant Start Ballast	✓
105	SUNPARK	U-2/32ISE-HBF	Instant Start Ballast	✓
106	SUNPARK	U-3/32ISE-HBF	Instant Start Ballast	✓
107	SUNPARK	U-4/32ISE-HBF	Instant Start Ballast	✓
108	SUNPARK	U-1/32ISE-LBF	Instant Start Ballast	✓
109	SUNPARK	U-2/32ISE-LBF	Instant Start Ballast	✓
110	SUNPARK	U-3/32ISE-LBF	Instant Start Ballast	✓
111	SUNPARK	U-4/32ISE-LBF	Instant Start Ballast	✓

Item	Manufacturer	Model	Type	Compatible
112	SUNPARK	U-1/32ISE	Instant Start Ballast	✓
113	SUNPARK	U-2/32ISE	Instant Start Ballast	✓
114	SUNPARK	U-3/32ISE	Instant Start Ballast	✓
115	HOWARD	EP3/32IS/MV/MC/HE	Instant Start Ballast	✓
116	KEYSTONE	KTEB-432-UV-IS-N-P	Instant Start Ballast	✓
117	KEYSTONE	KTEB-432-UV-IS-N-P	Instant Start Ballast	✓
118	PROLUME	EP232IS/L/MV/SL	Instant Start Ballast	✓
119	PROLUME	EP232IS/L/MV/HE	Instant Start Ballast	✓
120	RADIONIC	E232H12	Instant Start Ballast	✓

Note: 1, This tube maybe can not work with the ballasts in the above list because they are too old or maybe have special technical data.

2, This tube maybe can work with the ballasts which not covered by the above list because there are so many ballast models.

3, Do not make mass installation without testing.