STEP 1

Prepare your tumbler system.

Remove all parts (lid, straw, Base Bottle, and the Boost™) from the packaging, wash with soap and warm water, and wait until dry before assembling.



This ensures your tumbler is clean and ready for use.



STEP 2

Assemble for your needs.

For 20oz (Base Bottle only)



- · Attach the straw to the lid's built-in port.
- · Screw the lid directly onto the Base Bottle.



 Sip your drink hands-free OR lift the lid's edge to drink directly from the spout.




· Perfect for coffee, tea, or light hydration.





Modular Tumbler System Hse & Care

For 40oz (with Boost™)

- To add capacity, adjust the expandable straw to full length.
- Twist the the Boost™ onto the Base Bottle. ensuring it's securely tightened to prevent leakage.







PRO TIP

Always tighten all parts securely to prevent leaks



Stack Boost™ and mix colors to fit your vibe and hydration needs.

CARE



Base Bottle: Dishwasher safe.

Boost™: Hand wash only.

Wash before initial use.

After use, wash all parts in warm, soapy water. No bleach.

Dry before storing and assembling.

⚠ Usage Restrictions:

- · Keep away from children when containing hot liquids.
- · Always test temperature before drinking.
- Hot liquids may cause pressure build-up open with caution.
- · Temperature changes or altitude shifts can increase bottle pressure, potentially causing leaks. Always open carefully.

X DO NOT:

- Place in microwave oven.
- · Place in conventional oven
- Place on stovetop
- Freeze
- Use with carbonated beverages when sealed
- · Use with dairy-based beverages for over 24 hours
- Store liquids in bottle for more than 24 hours
- Use for food storage
- Use as a cooking vessel
- · Not recommended for children under 3 years
- Adult supervision required for children under 12



See EurekaLifestyle.com for more use and care instructions.



0:07 / 0:

eurekalifestyle.com



eureka.lifestyle



support@eurekalifestyle.com

