


USER MANUAL



1. Long press "⏻" ① for 1.5 seconds with light on and it will be in standby mode.
2. In standby mode, short press "⚡" ② to activate vibration function: short press "⚡" ② can change among 8 modes, long press "⚡" ② for 1.5 seconds to switch off the vibration mode.
3. Short press "C" ③ to activate suction mode: short press "C" ③ can change among 10 modes, long press "C" ③ for 1.5 seconds to switch off the suction mode.
4. Long press "⏻" ① for 1.5 seconds to switch off the motor and light.
5. The light flashes while charging and will be on when the charging is completed.

SPECIFICATION

Material :	Silicone+ABS
Size :	222*93*40mm
Mode :	8 mode vibration, 10 mode suction
Charging time :	120mins
Using time :	60mins
Waterproof :	IPX5

PRODUCT DESCRIPTION

1. Clitoral stimulator with light suction and vibration to wow all of those sensitive nerve endings.
2. Combining sweet suction with pulsating vibrations, this clitoral vibe heralds a new age of female orgasms.

SAFETY

1. Don't share it with others for your health.
2. Stop using it if you feel uncomfortable.
3. Stop using it if you find the head of the product is not smooth enough or broken.
4. Keep it from children's reach.

CLEANING AND STORAGE

1. Please clean it thoroughly before and after using.
2. Warm water and medicinal alcohol can be used to clean this product, but warm water is highly recommended.
3. Naturally air dry and avoid direct sunlight.
4. Store it in a dust-free place.

ATTENTION

1. Please charge it before using.
2. Please use good quality personal lubricant. Something (Massage oil, hand cream or cleaning solution etc.) containing hazardous substances cannot be used as lubricant.
3. Once the battery has been fully charged, unplug the toy's DC plug.

12X7cm