


# PLANTERS

## OF STEEL

### INSTALLATION MANUAL

#### Planter Rectangle

CPT.12010040



x16

40 17 M6x16 bolt



x16

4032 M6 nut



x32

7093 M6 ring



x16

40 17 M8x16 bolt




x16

4032 M8 nut




x32

7093 M8 ring




x2

CPT.WA10040



x2

CPT.WA12040



x4

CPT.BS90

