



**Next, tuck the side securement straps through the plastic shroud and secure the velcro in back**



**Remove the center headrest by pressing the buttons on the sides, and pull over the top cover. Side headrests are NOT removable. Slide the side headrest through the headrest opening**



**Next, Pull the cover back and push through the rear.**

**Tuck the seat cover under the headrest & secure**  
**\*BEFORE THE NEXT STEP, SLIDE THE SEAT BELT THROUGH THE OPENING IN THE TOP OF THE COVER**



**After that, pull the cover behind the seat tightly & secure the Velcro Hook on the cover to the bottom of the seat.**

**Pull Down Tightly and secure to the bottom of the seat**