

Cabana Shade Set Up Guide

Set Contents

- 1 Cabana Shade
- 4 Sandbag Anchors
- 4 Tent Poles
- 4 Ground Stakes
- 1 Carry Bag

You're ready for a day in the sun! Start by setting up some shade.

- 1. Unfold the Cabana Shade and lay it out flat on the ground.
- 2. Place the front of the shade facing into the wind.
- 3. Fill the anchor sandbags completely. They will work better when fully filled.
- 4. Pull the anchors out at an angle. The shade material is very flexible so stretch the Cabana taut.
- 5. Assemble 2 tent poles, or 3 or 4 depending on the setup you plan to use. See Additional Tips!
- 6. Place the foam ball end of the pole under the shade at the front corners.
- 7. Stand the pole up while keeping the ball in place and plant the end of the pole firmly on the ground.
- 8. Sandbag anchors may slide while positioning poles. Ensure lines are taut, reposition the anchors if necessary.
- 9. If using 3 or 4 poles, repeat the procedure with the other 2 poles. Place the remaining poles at the rear of the Cabana 12-24 inches from sides and rear edges. Repeat steps 5-8.

1. Place front facing into wind 3. Stretch anchor lines tight 4. Place poles 12-24" from corners

Additional Tips:

- If you are having difficulty, the most likely solution is to stretch the material more. Fill the sandbags more and place them farther out.
- Wind can be good and bad. A light wind flowing in the front will lift the shade, creating more headspace. Stronger winds may cause instability.
- 2 poles may be more stable than 4 in stronger winds. Also, placing tent poles at a slight angle, with the top facing into the wind, may help with stability.
- 4 poles can allow for more shade, and works best in calm conditions.
- If wind causes anchor bags to slide, try burying the bags in holes covered with sand or using ground stakes.
- Tent poles can be adjusted for maximum stability. Some experimentation may be required.
- Try different configurations! Use 2 poles in diagonal corners for more shade when the sun is low. Use 2 poles centered front and back for a pup tent. Use 3 poles, 2 at front corners, 1 in the opposite side middle, for a tripod effect.

If you have any questions or problems, please contact us, we are glad to help!

Visit Fofana.co/Cabana

Customers value reviews written by other customers who purchased this product. We would appreciate if you wrote a review that reflects your experience with the product.