

SETUP INSTRUCTIONS

STEP 1:

Remove Pod from carry bag and stand upright with hub up. Ensure all feet and legs are properly assembled. Unfold legs.



STEP 2:

Grab 2 upper frame arms and lift up and out. Rotate the arms outward to expand the frame structure. You may need to assist the other 2 frame arms into position.



Fofana **POD**


All-Weather Sports Tent



Correct



Incorrect



Press down to lock



SCAN ME
FOR TIPS

Visit Fofana.co/Pod or
email support@fofana.co

WARNINGS:

Do not use a heater or flame of any kind inside POD, including smoking in or near POD. Always supervise children when using the POD. POD can be used in sun, but additional sunscreen is always recommended.

STEP 3:

Ensure the lower hub is locked into place correctly. Grab 2 short frame arms and press down to lock hub into place.



STEP 4:

Extend the telescopic legs until fully extended and they 'click'. Ensure all clips that attach the tent to the frame are secure. Spread feet out and stake them to ground.



TAKE DOWN INSTRUCTIONS

STEP 1:

Unzip windows and door 1/4 to 1/2 way to let air escape. Collapse telescopic legs. Push the button and press the middle section into the bottom leg section.

STEP 2:

Squeeze hub arms together and lift up. Collapse the frame structure inward. Carefully lift and rotate to allow frame to fold properly.



STEP 3:

Continue to collapse structure and set tent down.



Fofana **POD** All-Weather Sports Tent



Squeeze to unlock

CARE INSTRUCTIONS AND TIPS:

Clean windows by wiping with water and washcloth. If necessary, a soft brush and warm soapy water may be used.

Fogging or condensation may occur, open a window or two slightly to vent.

Use tent pegs/stakes to anchor whenever possible. POD is lightweight for easy carrying so it may move in wind.

Extreme care should be used moving POD when set up. Moving the POD with chairs inside may damage floor. Dragging your POD may cause permanent floor damage.

Be sure to dry POD thoroughly before folding and storing in the carry bag.

If POD is wet, it may be folded up to carry home, but should be set up in a well ventilated area to dry completely.

Never store the POD wet for extended periods longer than a few hours.

Please contact us if you have any questions or problems, we are glad to help!

Visit Fofana.co/Pod or email support@fofana.co

RAINFLY - SUN SHADE INSTRUCTIONS

STEP 1:

To convert to Sun or Beach mode, unhook toggle and ring connections in 17 places. 4 places per leg plus 1 at the top center.



STEP 2:

Remove lower feet from poles. Twist 90° and remove foot.



STEP 3:

To reassemble Pod, perform the above steps in reverse order. Set up Rainfly so hub is open and locked, but legs not extended. Ensure Pod and Rainfly are oriented correctly. After reattaching 17 connectors, the legs may be extended. Be sure to attach all 17 connectors or damage may occur.

CAUTION:

Sunshade should only be used by itself in calm conditions. Sunshade must be staked to the ground, and may require additional ropes to securely anchor to the ground. If used in strong winds, irreparable damage may occur.