



EAGLE LIGHTS 7" LED HEADLIGHT INSTALLATION INSTRUCTIONS

Eagle Lights 7" LED Headlight Installation Instructions

Our products use the latest state-of-the-art technology and the best available parts for the most reliable LED products for your motorcycle.

We offer the best and most comprehensive warranty in the business backed by excellent support and technical help. If you have questions, please feel free to call us at 1-800-921-3162 or email us at Support@EagleLights.com.



Attention!



Please read before installing.

- **Warning:** To prevent possible electrical shock, disconnect the negative battery terminal before installing this product.
- **Fitment Note:** 2014-2019 Harley-Davidson® Street Glide®, Electra Glide®, Ultra®, and TriGlide® Models will require the 69200897 harness for a plug and play installation.
- **Fitment Note:** 2014-2019 Road King® models require the 69200899 adapter for a plug and play installation.
- **Fitment Note:** 2013 and older Harley Davidson Touring Models will need part number 8700R for a direct fit in the headlight bucket.

Installation:

1. Disconnect the negative lead to the main battery.
2. Check your models manual for changing and replacing the stock headlight.
3. Remove the factory headlight from the housing.

4. Install the LED headlight into your motorcycle: Connect the harness from the LED headlight to the harness on the motorcycle. If the connection type is different, you may need an adapter harness.
 - a. If the harness is a flat style plug with 4 pins, you will need the **69200897** harness.
 - b. If the harness is two separate plugs with two pins in each, you will need the **69200899** harness.
 - c. If you can't get the trim ring to sit onto the motorcycle bucket, you will need the **8700R** adapter ring. It is needed on all Harley Davidson Touring Models that are 2013 or older.
 - d. Test the headlight to ensure that the high beam and low beam are working correctly.

Halo Model LED Headlights

All 7" LED Halo model LED headlights are equipped with a preinstalled harness for the halo ring. The halo ring will illuminate on the low beam and automatically turn off on the high beam.

Slim Line / Infinity Beam LED Headlight Models:

Models come equipped with an extra red wire. It provides power to the DRL bar in the center of the light. Can be connected to any 12V constant power source. This does not need to be connected if you do not want to use the functionality.

If you are having any issues installing the headlight, please contact us. We can provide technical help on the phone (1-800-921-3162) or via email (support@eaglelights.com)