



# Eagle Lights

## 8700R Adapter Ring

### GENERAL

#### Installation Requirements

#### WARNING

The rider's safety depends upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a local dealer perform the installation. Improper installation of this kit could result in death or serious injury.

Separate purchase and installation of extra parts or accessories may be required for proper installation of this kit. **2014 and later FLHR, FLHRC and FLHRSE Models** require kit 8700\_PKRP. **2006 - 2010 FLHTCUSE Models** require harness jumper.

#### NOTE

*This instruction sheet refers to service manual information. A service manual for this year/model motorcycle is required for this installation. One is available from your local dealer.*

1. See the service manual to remove the main fuse.
2. See the service manual. Follow the instructions to replace the headlamp, removing any trim rings and hardware.  
**All Models except Touring:** Save the hardware, retaining ring and trim ring for installation. **Touring Models:** Will need the adapter ring for installation (8700R).

3. **Touring Models:** If the motorcycle has a mounting ring: Remove the mounting ring and mounting ring hardware. Discard the mounting ring and headlamp, Will need part number 8700R to finish installation.
4. Disconnect the harness. To remove the headlamp:
  - a. **2006-2010 FLHTCUSE Models:** Unplug cigar lighter and garage door opener to remove existing jumper harness.
  - b. **All other Models:** Remove existing jumper harness.

### INSTALLATION

#### WARNING

**Connect positive (+) battery cable first. If positive (+) cable should contact ground with negative (-) cable connected, the resulting sparks can cause a battery explosion, which could result in death or serious injury.**

1. Unscrew the trim ring from the bike.
2. Remove the OEM headlight.
3. Remove old headlight ring. Uses Torx Driver bolts for most applications.
4. Using the same hardware from the previous step, install the new adapter ring.
5. Remove the 3 screws from the top ring of the new adapter ring.
6. Install new headlight into ring.
7. Re-Install the top ring from the adapter ring.
8. Re-Install the trim ring.

If you need more detailed information on how to install the headlight. Please see our website at [www.EagleLites.com/pages/downloads](http://www.EagleLites.com/pages/downloads) to get more information on your product.