BRAINWAV7®

HEADPHONE HANGERS 3MTM VHBTM TAPE APPLICATION GUIDE

Safety Guidelines

- Do not stick or attach 3M[™] tape to bare skin.
- Do not attach 3M[™] tape to loose or crumbling plasterwork.
- We advise not to attach 3M[™] tape to main walls / decorative walls as tape is very strong and may damage paints and wallpapers.
- Do not attach 3M[™] tape to unprepared surfaces.
- 3MTM tape is very strong and adheres almost instantly please ensure you line up and align the item correctly before allowing tape to touch the surface.
- Take care when removing 3M[™] tape from any surface as it may cause damage.



User Guide and Warranty Card


In case of any problems please contact us by email:



help@yourbrainwavz.com

Applying 3M™ VHB™ Tape

- Make sure the surface of your choice is clean before attaching your product. For the
 3MTM VHBTM to build a strong bond between the hanger and the surface of your choice,
 it must be dry, clean and free of oil and dust.
- For much better results, you can use a hair dryer to warm up the surface before applying the 3MTM VHBTM tape. Do NOT use a heat gun as this may damage the hanger and any surfaces!
- Test-fit the hanger to your desired surface (do not remove backing). Your location should be free of any gaps or holes, for a stronger and safer fixing. For a more precise placement, you can mark the exact position before placing the hanger.
- Remove the backing off the VHB™ tape and carefully stick hanger in desired location.
- Apply pressure by pressing the product A hard onto the surface B. This will help to develop high-strength adhesion and bonding. Bond strength will increase over time, after application.



•


To ensure a more secure bond has been achieved, do not use your new hanger for at least 24 hours after installation! Using the hanger right after installation, will affect the result and the hanger may be falling off.

Bonding Strength:

- 20 minutes is only 50%
- 24 hours is 90%
- 72 hours is 100%

Removing 3M™ VHB™ Tape

- Do not just pull your hanger off the surface this may cause damage!
- Heating the 3M[™] tape gently with a hair dryer prior to removal may help in loosening the tape from the surface. Do NOT use a heat gun as this may damage the hanger and any surface!
- Ensure a slow and gentle removal 3M™ VHB™ is extremely strong and may result in damage to the surface if removed incorrectly.
- Gently apply pressure on one end of the hanger A, tilting it slowly to increase the angle B and remove the hanger and the 3M[™] VHB[™] tape.
- Remove any excess tape from both the hanger and surface by hand, a hair dryer may help in loosening any remaining tape, clean with gentle cleaner.



3M and VHB are trademarks of 3M Company. Visit www.brainwavzaudio.com for latest information on all Brainwavz products.

Brainwavz Model:	Date of Purchase DD MM YYYYY	RMA/Order Number:
Your Name		
Your Email Address		
Your Mailing Address		
Vendor		
Description of Prob l em		
To facilitate warranty, please contact the authorized vendor the product was purchased from. 54401261		