

KIDWAVZ

BRAINWAVZ KV100

User Manual & Warranty Card

Contents & Accessories:


- KIDWAVZ Bluetooth Headphones
- USB Charging Cord
- 3.5mm AUX Cord
- Instruction Manual & Warranty Card

Safety Instructions

Read this manual carefully before putting the device into operation and keep this manual for future reference.

- Do not use the unit with wet hands.
- To minimize the risk of fire or electrical shock, avoid operating in wet conditions such as rain or humidity. Do not operate around water (e.g. bathroom, swimming pool, etc.)
- Do not insert any metal object into the device.
- To avoid static charge, do not use the device in an extremely dry climate.
- Do not attempt to repair the device yourself.

Description of Buttons

-  Power on/off, Play/Pause, Pick up/Hang up phone call
- V+** Volume Control (Increase Volume)
- V-** Volume Control (Decrease Volume)
- ◀◀** Previous Track
- ▶▶** Next Track

Charging Instructions

The KV100 come with a built-in rechargeable battery. Before using it for the first time you should charge the battery fully. Only use the supplied USB cable to charge the Bluetooth headphones.

1. Connect the USB cable to the USB port on the unit.
2. Connect the other end of the USB cable to a USB port on a PC or an AC/DC adapter. The LED indicator turns red to indicate that the battery is being charged. When the battery is fully charged, the red LED indicator will turn off.

Pairing Instructions Bluetooth Device

1. Turn off the headphones
2. Press and hold the Phone button until the red LED light flashes, now the Bluetooth headphones are ready for pairing.
3. Turn on your Bluetooth enabled device and activate the Bluetooth function.
4. Search for the Bluetooth device, "KV100" will show up.
5. Pair your Bluetooth enabled device with KV100. If a password is required, type in "0000". After the KV100 is paired with your device, connect it to your device.

Tips:

Once the KV100 are paired and connected to your Bluetooth device, they will automatically connect next time as long as the Bluetooth function on your device is turned on.

Control a phone call via headphones

Answer a call:
Short press the Phone button.

End a call:
Short press the Phone button.

Redial the last number:
Press the phone button twice quickly.

Using AUX input

The AUX input function allows you to use your headphones without using the battery and the Bluetooth connection.

Note: Please switch off the headphones when using AUX input.

IMPORTANT: Volume limiting is only on Bluetooth mode. Please manually lower volume for AUX.

Care and Maintenance

Read the following recommendations before using the Bluetooth headphones. Following these you will be able to enjoy the product for many years.

- Do not expose the Bluetooth headphones to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- Don't use abrasive cleaning solvents to clean the Bluetooth headphones.
- Do not expose the Bluetooth headphones to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Don't dispose of the Bluetooth headphones in a fire as it will result in an explosion.
- Don't expose the Bluetooth headphones to contact with sharp objects as this will cause scratches and damage.
- Don't let the Bluetooth headphones fall on the floor. The internal circuit might get damaged.
- Don't attempt to disassemble the Bluetooth headphones as it may get damaged if you are not professional.

Product Specifications

Bluetooth Profiles:	HSP, HFP, A2DP, AVRCP
Bluetooth Operating Distance:	10 meters / 33 feet
Frequency Range:	2.4 - 2.48 GHz
Frequency Response:	100 Hz - 20kHz
Distortion:	≤1%
Microphone Sensitivity:	-40dB
Working Time:	Music Play Time up to 6 hours Talk Time up to 10 hours
Charging Input Power:	DC 5V
Charging Time:	Approx. 3 hours

Note: Battery life & charging time may vary, based on usage & types of devices used.

12 Month Warranty

Warning: You should not use any earphones and headphones at excessively loud levels. Sealed eartips and lower listening levels allow for longer periods of safe listening. Using earphones and headphones at high volumes or for extended periods of time (more than 1 hour period per day) can permanently damage your ears. Ringing in your ears or other discomfort can indicate that the music volume is too high. For safety reasons DO NOT use earphones and headphones while driving a car, biking, walking or operating machinery. Keep your earphones or headphones away from young children, this product includes small parts and cables which may create a choking hazard.

Warranty: BRAINWAVZ warrants that this product shall be free from defects in material or workmanship for a period of 12 months from the date of purchase from an authorized BRAINWAVZ distributor or reseller. Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser. This warranty gives you specific legal rights, and you may also have other rights that vary under local laws.



In case of any problems, please contact us by email:

help@yourbrainwavz.com



Warranty Card (12 Month Warranty)

Brainwavz Product: _____ Vendor: _____

Date of Purchase: _____ RMA / Order Number: _____

Your Name: _____

Your Email Address: _____

Your Mailing Address: _____

Description of Problem: _____

To facilitate warranty, please contact the authorized vendor the product was purchased from.