





GOATEE SHAVING TEMPLATE




Instructional Manual

CLEANING



First Use:

Clean GoateeSaver thoroughly with liquid soap and warm water




After Use:

Clean with running water. Lay your GoateeSaver with the Mouthpiece facing up and extended away to allow for complete drying.

HOW TO SHAVE

For the first shave, it is best to trim the goatee to a shorter length because it will be easier to shape. It's best to use the guard trimer of 1 thru 5. Using the 1 guard setting is the best. It is not a requirement to trim down your goatee but it will just make it easier. The second time you shave it is not necessary to cut short.



Guides Adjustment:

Adjust Guides to personalize your goatee shape.

Adjust the three rollers on the front. Only adjust them one at a time and only turn 1/4 rotation each time. This is important so as not to get the rollers stuck. Turn bottom roller 1/4 turn then stop. Turn middle roller 1/4 turn then stop. Finally, turn top roller 1/4 turn then stop. Repeat this process until you have the width you desire. Make final adjustments to specific rollers for the final shape you desire.

HOW TO SHAVE

#1



#2



#3




Mouthpiece Adjustment:

Most users do not need to adjust the mouthpiece, but if you do, please follow these instructions: Hold MY PERFECT GOATEE™ tightly with one hand, press in and twist the mouthpiece. Afterwards, both

sides should be in the same space. You might be surprised by the amount of force needed to adjust the mouthpiece. Don't worry, you will not break it.

HOW TO SHAVE



Apply shaving cream to your face. Put MY PERFECT GOATEE™ in your mouth, line up the center of MY PERFECT GOATEE™ with the center of your nose, and bite on mouthpiece. Use whatever hand you're not shaving with to firmly hold

MY PERFECT GOATEE™ in place and apply pressure to template towards your face to make sure the template does not move while shaving.

Shave downward with the edge of razor against the Guides to get the perfect symmetrical goatee.

OTHER Important Shaving Tips:

Make sure the razor stays straight up and down to ensure an even shave. This is very important when shaving on the left side of your face (if you use your right hand to hold razor). If razor is angled, then the shape won't be as even on both sides. The Goatee-Saver can be used with a traditional or electric razor.

LIMITED WARRANTY

GoateeSaver guarantees its products against defects in material and craftsmanship for one year. This warranty does not cover damage caused by misuse, and is limited to product repair or replacement at the company's discretion. The customer is responsible for shipping the item back to the GoateeSaver Company, LLC.

For warranty repair or replacement:

Send service request to:

service@myperfectgoatee.com

www.myperfectgoatee.com

2001 Brownwood Rd

Little Rock AR 72207

