


Adding the Three Way Switch Option

- The three way switch option is used mainly for our Krista Lights. This option is used in situations where the rider wants to be able to use the Krista Lights in three different settings: Regular function, off, and high beam only. Some riders like this option because it allows them to ride with their Krista lights on only when their high beams are on. Since our Krista lights are so bright, it is unsafe to keep them on at all times even if dimmed fully, and instead of having to switch them on and off constantly for oncoming traffic, they can be integrated to work with the high beams only.
- To install the switch, run a wire from a 12V power source to the switch. A relay must be placed between the 12V and On 2 position in order for the lights to work in sync with the high beams only.



Wiring Schematic

