



Jackery Armor  
User Guide

## Product Overview

### Package Content


- 1\* Jackery Armor
- 1\* Micro USB Cable
- 1\* User Manual
- 1\* Thank you card
- 1\* Compass
- 1\* Carabiner

### Technical Specification

Model: Jackery Armor  
Capacity: 3.6V 9000mAh (32.4Wh)  
USB Output: 5V 2.1A  
Input: 5V 2A  
Dimension: 3.98\*2.54\*1.06inch /101\*64\*27mm  
Weight: 7.76Oz/ 220g  
International Protection Marking Rating: IP67 (When ports seal cover is closed, all ports, LED Flashlight, and internals are completely protected against dust, snow and water up to 3ft/1M FOR 30 minutes)

## Instruction

### Product Layout




Note: Press the power button twice to switch on/off the flash light

## Instruction

### Charge your device

Connect Armor to device via USB output port. Press the Power Button to start charging your device.




The Armor is compatible with most USB powered peripherals.  
NOTE: Cable not included for other devices. Please use your original charging cable.




## Instruction

### Recharge your Jackery Armor

Charge via any 5V / 2A USB adapter for optimal charging (adapter not included)




Alternate method:




## Instruction

### Jackery Armor LED indicator

When charging device, press the Power Button:



When recharging PowerActive:



LED Light - Flashing   LED Light - on   LED Light - off

## Instruction

To keep you never out of power, it's time to recharge the battery when there is one LED light blinking. We highly recommend you to recharge the battery at least once a month.

Follow @jackeryinc on Twitter & Facebook  
[www.facebook.com/jackeryinc](http://www.facebook.com/jackeryinc) for the latest Jackery news, tips and updates! You can also visit [www.jackery.com](http://www.jackery.com) for more info.



Warning

Read all instructions and warnings prior to using this product. Failure to read and follow these safety instructions could result in fire, explosion, electrical shock or other hazard, causing serious and/or fatal injury and/or property damage.

1. Do not modify, disassemble, open, drop, crush, puncture or shred the product.
2. Do not expose the product to rain or water.
3. Keep away from open flame or sunlight to prevent heat build-up.
4. Keep away from high voltage devices.
5. This product is not a toy, keep away from children. Ensure that all persons who use the product read and follow these warnings and instructions.

## Warranty

This product is covered by a limited warranty from Jackery for the original purchaser that covers the product from defects in workmanship and materials for 24 months from the date of purchase (damages through normal wear and tear, alteration, misuse, neglect, accident, service by anyone other than the authorized service center, or act of God are not included).

During the warranty period and upon verification of defects, this product will be replaced when returned with proper proof of purchase.

### Contacts us

For any inquiries or comments concerning our products, please send an email to [hello@jackery.com](mailto:hello@jackery.com), and we will respond to you as soon as possible. If there is any quality-related issue with the product, you may request a REPLACEMENT or REFUND by submitting a request form at [www.jackery.com/support/](http://www.jackery.com/support/).