




# Jackery Bar

## User Guide

### Product Overview

#### Product Layout



1. LED light indicator
2. Power button
3. Micro USB input port 5V / 2A
4. USB output port 5V / 2.1A
5. LED flashlight

#### Technical Specification

Capacity: 6000mAh  
Dimensions: 3.9 x 1.8 x 0.8 inch  
Weight: 5.3 oz  
Input: Micro USB 5V / 2A  
Output: Smart Fit 5V / 2.1A  
Power indication: Three LED indicators


### Instruction

#### Package Content

- Jackery Bar Battery Pack
- Micro USB Charging Cable
- User Guide & Warranty
- Thank You Card

#### Charging Jackery Bar


To charge the Jackery Bar, use the micro USB charging cable to connect the Bar to a USB AC adapter or computer USB port. The LED indicator will show on or start blinking.  
When all three LEDs are on solid, charging is complete. It takes about 4 hours to fully charge the Bar.



### Instruction

#### Charging Your Device

To charge your device, use a USB charging cable to connect the Bar to your device, then press the power button once to initiate charging.



It is recommended to use the original AC adapter and USB charging cable of your mobile device.

#### Check the Battery Level

Press the power button once to check the battery level by reading the LED indicators from right to left.  
1 LED blinking: level < 10%  
1 LED on: level in 10%-33%  
2 LEDs on: level in 33%-66%  
3 LEDs on: level in 66%-100%

#### LED Flashlight Function

Press the power button two times to turn on the LED flashlight. Press it again two times to turn off.

### Warnings

When there is one LED light blinking, it's time to recharge the battery. We highly recommend you to recharge the battery at least once a month.

Follow @jackeryinc on Twitter & Facebook [www.facebook.com/jackery.inc](http://www.facebook.com/jackery.inc) for the latest Jackery news, tips and updates! You can also visit [www.jackery.com](http://www.jackery.com) for more info.



#### Warning

Read all instructions and warnings prior to using this product. Failure to read and follow these safety instructions could result in fire, explosion, electrical shock or other hazard, causing serious and/or fatal injury and/or property damage.

1. Do not modify, disassemble, open, drop, crush, puncture or shred the product.
2. Do not expose the product to rain or water.
3. Keep away from open flame or sunlight to prevent heat build-up.
4. Keep away from high voltage devices.
5. This product is not a toy, keep away from children. Ensure that all persons who use the product read and follow these warnings and instructions.

### Warranty

This product is covered by a limited warranty from Jackery for the original purchaser that covers the product from defects in workmanship and materials for 18 months from the date of purchase (damages through normal wear and tear, alteration, misuse, neglect, accident, service by anyone other than the authorized service center, or act of God are not included).

During the warranty period and upon verification of defects, this product will be replaced when returned with proper proof of purchase.

#### Contacts us

For any inquiries or comments concerning our products, please send an email to [hello@jackery.com](mailto:hello@jackery.com), and we will respond to you as soon as possible. If there is any quality-related issue with the product, you may request a REPLACEMENT or REFUND by submitting a request form at [www.jackery.com/support/](http://www.jackery.com/support/).