

Ultimate Skin Spa

Facial Cleansing System

User Guide

Experience spalevel, custom facial cleansing at home.

Features

The deepest clean

Gently but thoroughly removes hard-to-get dirt, makeup, debris and dead skin cells

Shower Friendly

Water resistant—perfect for the skin or shower

At home or on-the-go

Includes a hard protective case for storage and travel

No cords needed

Powered by 2 AA batteries (Not included)

The Vanity Planet Ultimate Skin Spa is a dual-speed spin brush that purifies your skin to help reveal your natural glow. With three interchangeable brush heads—Cleansing Brush, Exfoliating Brush and Silicone Brush—it ensures all your facial care needs are met. Its convenient travel case keeps your set clean and collected, perfect for traveling or or safe storage at home. With two speed settings, you can use the lower speed for a gentle, topical cleanse, or the higher speed for deeper exfoliation.



Getting Started

USING YOUR BRUSH HEADS

- Remove makeup with a cleansing towelette or wipe before using the attachments to avoid staining the bristles
- 2. Attach your desired brush head
- 3. Dampen your skin with water
- Apply cleanser directly to your skin or the brush head.
 Avoid using exfoliators with large, jagged particles
- 5. Hold the device so the brush head is flush against your skin, then press the power button to select a mode
- Gently glide the Ultimate Skin Spa over your skin's surface in a rotating motion, careful not to apply too much force to the brush head as this may cause irritation to your skin

INSERTING THE BATTERIES

Remove the battery cover by moving the battery lock to the open position at the bottom of the handle. Install 2 AA-batteries (not included), matching the polarity symbols as you install. Replace the cover and slide the battery lock back to the closed position.



Daily Cleansing Brush

This brush gently lifts away debris and dead skin cells better than manual makeup removal.

Ultra-soft bristles for a complete (yet gentle) clean

Use it daily for radiant skin

A mild cleanser is its perfect pair



Exfoliating Brush

This brush removes deep-seated dirt and debris from the lower layers of skin to help those who are acne-prone.

Firmer bristles for a deeper clean

Use 2-3 times a week

Pair it with a mild cleanser and avoid harsh exfoliants

Silicone Brush

A brush that gently cleanses sensitive skin and acne-prone skin to loosen dirt and unclog pores.

Soft, hypoallergenic bristles

Use it daily

Pairs perfectly with a mild or hydrating cleanser



Reveal your radiance.



Taking Care

To keep your Ultimate Skin Spa in good shape, don't use abrasive cleaners or chemicals to clean any part of the device. Make sure to store it in a cool, dry place.

CLEANING THE BRUSH HEADS

Rinse the brush heads thoroughly after each use. If they are discolored from makeup or debris, clean them with warm, soapy water.

CLEANING THE DEVICE

To remove any residue or buildup, clean the base and handle once a week by taking a slightly damp cloth and wiping down the body of the device.

BATTERY DISPOSAL/RECYCLING INSTRUCTIONS

- Only install new batteries of the same type; don't mix old and new batteries
- Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak
- Do not mix old and new batteries, and do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium or Nickel Metal Hydride) batteries
- Do not dispose of batteries in fire
- Batteries should be recycled or disposed of as per state and local guidelines

Tips & Warnings

To experience the full range of benefits from the Vanity Planet Ultimate Skin Spa, we recommend the following:

- Do not share your brush heads with anyone
- Do not submerge the handle in water
- Do not use with harsh exfoliating cleansers or physical exfoliants such as nuts, shells, seeds or other jagged exfoliating particles
- Using your Ultimate Skin Spa to remove makeup may stain the bristles of the brush head; if discoloration occurs, clean the brush head with soap and water
- For best results, change your brush heads every 2 to 3 months

One-Year Warranty

This Vanity Planet product is warranted to be free of manufacturer's defects in materials or workmanship for one year from the date of purchase. Damage or wear resulting from an accident, misuse, abuse, commercial use, or unauthorized adjustment and/or repair are not covered under this warranty.

Should this product require warranty service (or replacement at our discretion) please contact client service to obtain a Return Merchandise Authorization number (RMA) and return instructions; proof of purchase is required. Products returned without a Vanity Planet generated RMA number will not be accepted and the sender will not receive a refund, replacement, or repaired product.

VANITYPLANET.COM INFO@VANITYPLANET.COM 1.888.870.2132

There are no express warranties except as listed above.
This warranty gives you specific legal rights and you may
have other rights which vary from state to state.

Please do not return this product to the retailer. Contact us directly for warranty service or repair, thank you.