

Model No. WL01
Caution: Read all instructions carefully before using this item.

Fabric Shaver Instructions

WONDER Lint



house of
WONDERFUL™

BEFORE YOU START

- Use this fabric shaver only as recommended in this manual.
- Use this fabric shaver on fabric only; it is not to be used on skin, hair or any other material.
- This fabric shaver is equipped with a sharp cutting blade, do not leave it unattended.
- Not to be operated by children.
- Tuck in any loose threads before shaving.
- Do not use this fabric shaver on delicate, easily damaged fabrics. If unsure test the fabric's suitability on an unexposed area first.
- Do not let this fabric shaver come into contact with water.

02


© 2015 The Station Products Pty Ltd.

www.houseofwonderful.com

house of
WONDERFUL™

COMPONENTS

1. Shaving Head
2. On/Off Switch
3. Removable Lint Collector
4. Comfort Grip Handle
5. Battery Compartment
6. DC Socket
7. A/C Adaptor
8. Replacement Blades
9. Cleaning Brush
10. Drawstring Bag



03

- Use a damp cloth to wipe the surface of your Wonder Lint®. Do not allow water or other liquid to enter the inner parts of this device.
- To clean the shaving head or blades, switch off and unplug your Wonder Lint®. Unscrew the shaving head and use the cleaning brush provided to remove any bobbles or lint pieces, then screw the shaving head back on. Blades are sharp so please use caution.
- To replace the blades, switch off and unplug your Wonder Lint®. Unscrew the shaving head, carefully remove the shaving blades and insert the replacement set. Then screw the shaving head back on. Blades are sharp so please use caution.
- If the screen cover is loose or open when the power is on the motor will shut down.
- Remove the batteries if your Wonder Lint® will not be used for a long period of time.

CARE AND CLEANING

1. To use with A/C adapter, plug one end into the DC socket on your Wonder Lint®, and the other end into an electrical outlet.
2. To use with batteries, pull out the removable lint collector to expose the battery compartment. Open the cover of the compartment via the clip on the left hand side. Install 4 C batteries, as indicated, close the compartment and clip the lint collector back into place.
3. Switch shaver ON.

PREPARATIONS FOR USE

- Your Wonder Lint® Fabric Shaver comes with a 100% Money Back Guarantee.
- Should your product be defective in any way simply return it and we will replace it or give you your money back.
- We are committed to giving our customers an amazing experience so please contact us at: hello@houseofwonderful.com if you have any questions.

100% MONEY BACK GUARANTEE

- Place fabric on a flat surface such as an ironing board and pull it as straight as possible.
- Tuck in any loose threads before shaving and test the fabric's suitability on an unexposed area first.
- Gently glide the shaving head over the fabric in an up and down motion.
- Do not press down heavily in order to prevent possible damage to fabric.
- Empty the lint collector after each use.

OPERATING INSTRUCTIONS