## **G-Mac Glide Evo**



**User Manual** 

## Anatomy of Helmet:



- Chin Bar Mechanism 1.
- 2.
- Micrometric Buckle 3.
- 4. DVS Thumb Slider

- **Intercom Recess Cover** 5.
- Drop Down Sun Visor (DVS) 6. Visor Release Mechanism
  - 7. Anti-Scratch Visor
    - 8. Air Vents





Pull on the flip mechanism and lift up the chin of the helmet

Push the chin all the way up until it snaps into place and stay up on its own



To close the chin bar, pull firmly from the bottom of the chin and close, until you hear an audible locking sound





**DVS SLIDER** 

**DVS SIDE VIEW** 

Slide the DVS slider back and forth to raise and lower your inner sun visor.

NOTE: Do not manually raise and lower the visor with your hands, always use the slider to prevent damage







To close the chinstrap fastener, slide the ratchet tongue into the locking buckle. When adjusting, make sure the strap rests firmly but not uncomfortable around your chin. To open the strap, pull the red ribbon the ratchet upwards to release the buckle. Then pull the other side out



To remove the visor, first fully open it



Press down on the spring loaded arm and the visor will pop out off of the mechanism



Once both sides have popped out, remove the visor



To reinstall the visor follow these steps in reverse

## **Additional Features:**



The switch that is uncovered when the chin bar is raised can be used to lock the chin in the upright position.



The intercom recess cover can be removed to allow the passthrough of cables to inside the helmet body.