

## Ceiling Hook Assembly Instructions

For use with

- FX9000 D Hanger Hook
- FX9001 C Hanger Hook
- FX9002 Ring Hanger Hook



### Package Contents:

- 1 x Hook of your chosen kind
- 1 x Knob
- 1 x Threaded Connector
- 1 x Channel Nut

### Tools Required:

None

Step 1: Check the parts received

Step 2: Screw the hook onto the threaded connector and tighten

Step 3: Slip the knob onto the connector and screw the channel nut onto the connector thread with 1/8" of thread past the nut. The side of the nut with the cross hatched groove is to face the knob.



Step 4: Position the connector into the PowerTrack channel. The nut should be inline with the channel opening.

Step 5: Turn the channel nut 90 degrees, pull down and turn the connector until it is tightened and facing the desired direction. Pulling it down seats the nut groove into the channel and prevents it from turning when tightening.