

SportClips® HAIRCUTS LUXURY MASSAGER

CONTENTS

Contents included in Sport Clips Luxury Massager Box



MATERIALS NEEDED

Sport Clips Luxury Massager required materials for use on the cutting floor:
Massager, Massager Attachment #6 & Charging Cord



DO's & DON'T's

Use Massager Attachment **#6** for MVP Experience on cutting floor.

Leave rubber cover on Massager Attachment **#6** for Client comfort.

Do **not** remove or discard rubber cover for Massager Attachment **#6**.

Massager Attachments **#1–#5** are **not** for cutting floor use.



STORAGE

During operating hours hang a Luxury Massager on a hook under each station.

** Please note when massagers are first recieved they require an hour charge before use.*



CHARGING

After closing plug a Luxury Massager charging cord in underneath each station & remove each massager from the hook, plug it in & set it on each work station to charge.



Before opening unplug & store Luxury Massager back on hook under each station Unplug and wrap up charging cord & store in lower locker at each staion.



Frequently Asked Questions for the New Massager

Q: Has the neck and shoulder massage procedure changed?

A: No, please continue to provide the same great experience.

Q: How long does it take to charge?

A: 1 hour will give a complete charge.

Q: How long does the charge last?

A: ISO Beauty would recommend that the massagers only be charged for 2 hours a day.

Q: Does it work when it is plugged in?

A: No, it must be unplugged for use.

Q: Can I try out some of the different heads?

A: No, only the soft black head is approved for use on Clients.

Q: Why do we grip it behind the head instead of the handle?

A: This grip makes it easier to control for the stylist. Holding it at the handle can allow it to bounce against the Client.

Q: Can my store use both style massagers?

A: No. The stations must all have the same style massager.

Q: Can the massager set on the stand or hang from the hook?

A: Either, but the store must be consistent.