



Selfie Stick Monopod - Cable




ZIX-2015C


User Manual



1. Twist Selfie Stick counterclockwise to unlock the monopod;
2. when the raised line of each segment matches to be one straight line, you can stretch or shorten the monopod freely;
3. Twist Selfie Stick clockwise to lock the monopod at your desired length.



1



1. Pull the phone mount to put the phone in and fix its position;
2. The phone mount is capable of 270° rear rotation.

2

Product Specifications

Net Weight	161g
Extended Length	97cm
Folded Length	23cm
Material	Aluminum Alloy
Flex Section	5 Segments
Color Options	Black/Grey/Silver/Pink/Blue

3

Selfie Handheld Monopod

Model: ZIX-2015C

Contains

1. Selfie handheld monopod
2. Water-proof carry bag
3. Wrist strap
4. User manual

Selfie Stick User Manual

1. Place your mobile phone into the phone holder;
- 2 Plug the audio cable of selfie stick into the headphone hole of mobile phones;
3. Open the camera function on your mobile phone, and press the shutter button on selfie stick holder for photo shooting.

4

Warning

1. Do not dismantle or modify the product;
2. Do not store the product in wet conditions;
3. Do not keep or use the product near the heat sources;
4. Do not let water or any other liquid flows into the inside part of the products' interface. This would cause damages to the product.

Disposal of Electronic Products

1. Do not place the product as household wastes;
2. Please dispose of discarded electronic products properly according to local regulations;
3. We encourage you to participate in electronics recycling program.

5

Warranty Conditions

For any defect, in the judgment of our technician, caused under normal use, we are responsible for free-of-charge repairing in 12 months from the date of purchase at the discretion of our company.

6

