

electro V2

Dip Your Hands Into Gloving

The Electro V2 Gloves combine high-quality, affordability, and ease-of-use all into one glove set to make it simple for you to dip your hands into gloving. Bust them out and show everyone your moves. Go out there and "Light Up The World"!

DEFAULT MODES



COLOR OPTIONS



Red

Orange

Yellow

Green

Sky Blue


Purple

Hot Pink

Silver

GETTING STARTED

1. Pull the white battery tab out from the pouch in the cuff of the glove. The lights will turn on.
2. Find the "ON/OFF" sticker. You will feel a small battery pack with a button along the edge.
3. HOLD the button to turn the lights OFF / CLICK to turn them back ON.
4. Slip the gloves on so that the battery pack sits on the back of your hand.
5. Pull the cuff down and stretch your fingers into the tips of the glove.
6. Cycle through all 7 mode options by clicking the battery pack's button
7. Hold the button down to turn the lights off at any time.



CUSTOM COLOR PROGRAMING

Each light on the Electro Gloves flashes 3 colors at once. Use the battery pack's button to select your favorite colors.

1. With the lights OFF, click and hold until the button flashes **orange**.
2. Click to cycle through the color options shown on the other side of this sheet.
3. When you find the color you want to program, hold the button, and your first color will be programmed.
4. Select your second and third color the same way. As you select, the lights will flash the colors that you've already chosen.
5. The 3 selected colors will now be applied across all 7 modes.

HOW TO CHANGE BATTERIES

1. Flip the cuff of each glove over to expose the wires & battery pack from the inside of the glove.
2. Gently pull out the battery pack from the pocket within the glove. Locate the small disk-like drive at the back of the battery pack.
3. Put your fingernail in the groove and pull the battery tray out.
4. Stack 2x 2020 batteries on top of each other with the + side facing up.
5. Place the batteries in the tray, and close.

REPLACING YOUR GLOVES

1. Flip the cuff of each glove over to expose the wires & battery pack from the inside of the glove.
2. Gently pull out the battery pack from the pocket within the glove, along with the rest of the wires from each finger.
3. Put each of the lights into the fingers of your new gloves until they are fully inserted.
4. Place the battery pack into the pocket inside of your replaceable glove. If your glove does not contain a pocket, that's okay, you can put your Electro V2 Glove Set on, and let the battery pack rest on top of your hand!

MASTER RESET

This will return the Electro Gloves to factory settings.

1. With the gloves OFF, click and hold the button.
2. The lights will flash **orange**, but keep holding.
3. Keep holding until the lights flash **white**, then release.

CLICKSWITCH BUTTON

With ClickSwitch, you can lock your favorite mode in ON/OFF function. For example, if you only want to use Strobe Fade you can use ClickSwitch to make the light turn on and off in that mode.

1. Turn the light ON and click to find the mode you want to lock.
2. When you're on the mode, click and hold the button until the lights flash **green**. Now your lights will turn on and off in that mode.
3. To return to 7 Mode function, turn the lights ON, and click and hold until **green** flashes again.