



Remington 870 Shotgun Saddle
Mount
USER MANUAL

FF34007

VICTORY JUSTIFIES EVERYTHING

Whether you are in a fast-paced combat situation or defending yourself and your home, Firefield™ will be by your side, preparing you for victory. Firefield™ offers quality products with outdoor enthusiasts and paintball fanatics in mind. Whether your weapon of choice is paintball, airsoft, AR15, shotgun or pistol, Firefield™ can accommodate your preference. Firefield™ will provide you with high quality and durability for a fraction of competitor pricing. Firefield™ products consist of boresights, flashlights, laser sights, reflex sights, rails, mounts, magazines, binoculars and other shooting accessories.

www.fire-field.com

Shotgun Saddle Mount 1- 8

English

To view this manual in different languages other than the ones provided visit
www.fire-field.com



Constructed from durable, aluminum, the Firefield Remington 870 shotgun saddle mount features a low profile design, weaver rail mount and a rail specifically designed to allow usage of iron sights. This lightweight mount includes two set screws, which replace trigger pins for secure attachment. Designed to work with Remington 870 pump action shotgun.

Specifications

Material	Aluminum
Rail type	Weaver
Dimensions	6x1.6x2.6in
Weight	4.2oz

DIAGRAM

Features:

- Durable aluminum
- Low profile design
- Rail specifically designed to allow usage of iron sights
- Two set screws replace trigger pins for secure attachment

Includes

- Shotgun mount
- Allen wrench
- Two set screws

1. Shotgun rail
2. Bolts



TOOLS NEEDED

- Shotgun Rail with included bolts
- 3mm Allen wrench
- 4mm Allen wrench
- Punch
- Hammer



INSTALLATION INSTRUCTIONS:

1. Before you begin, check to make sure the weapon is unloaded.
2. Using the punch (or Allen wrench) and hammer, gently tap the two pins above the trigger assembly until they are free. This will cause the trigger assembly to come loose, so you should use caution to prevent it from falling out.



3. Remove the two bolts (2) on the shotgun rail with the Allen wrenches (4mm for rear bolt, 3mm for front bolt). Next, slide the shotgun rail (1) over the top of the weapon and align the holes in the rail with the holes above the trigger assembly.



4. Insert the included bolts into the holes and tighten them with the Allen wrenches until they meet the other side of the Shotgun and are snug. Do not over tighten.

-
5. Mount desired optics or accessories on weapon.

TROUBLESHOOTING

Never ship back a product without getting proper authorization beforehand. Doing so could result in losing the product due to a multitude of reasons, i.e. sending it to the wrong address and other problems associated with unexpected packages.

1. If sight does not hold zero, check that the mount is securely attached. Also, verify the weapon sight is mounted securely. If there is any shifting, retighten the mounting system according to the mounting instructions, but do not overtighten.

FIREFIELD WARRANTY

Please visit www.fire-field.com for warranty details and information









www.fire-field.com